

Air conditioner
Installation Instruction

MODEL NO. :-
CU-TZ20, TZ25, TZ35, TZ42, TZ50, TZ60, TZ71WKE Series
CU-RZ20, RZ25, RZ35, RZ50WKE Series

Required tools for Installation Works

- 1. Phillips screw driver
2. Level gauge
3. Electric drill, hole core drill (70 mm)
4. Hexagonal wrench (4 mm)
5. Spanner
6. Pipe cutter
7. Reamer
8. Knife
9. Gas leak detector
10. Measuring tape
11. Thermometer
12. Megameter
13. Multimeter
14. Torque wrench
15. Vacuum pump
16. Gauge manifold

CAUTION
R32 REFRIGERANT

This Air Conditioner contains and operates with refrigerant R32.

Explanation of symbols displayed on the indoor unit or outdoor unit.

- WARNING: This symbol shows that this equipment uses a flammable refrigerant.
CAUTION: This symbol shows that the Installation Manual should be read carefully.
CAUTION: This symbol shows that a service personnel should be handling this equipment with reference to the Installation Manual.

SAFETY PRECAUTIONS

- Read the following 'SAFETY PRECAUTIONS' carefully before installation.
Electrical work must be installed by a licensed electrician.
The caution items stated here must be followed because they are related to safety.

Table with 2 columns: Symbol and Description. Includes WARNING, CAUTION, and prohibition symbols.

Table with 2 columns: Symbol and Description. Includes symbols for prohibited items and items to be carried.

- Carry out test running to confirm that no abnormally occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions.

WARNING

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
Do not install outdoor unit near handrail of veranda.
Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord.

- Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.

- For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.

- Do not use joint cable for indoor/outdoor connection cable. Use the specified indoor/outdoor connection cable.
Do not use joint cable for indoor/outdoor connection cable.
Do not touch the sharp aluminum fin, sharp parts may cause injury.

- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.

- Power supply connection to the room air conditioner.
Use power supply cord 3 x 1.5 mm (34 - 1.75HP), 3 x 2.5 mm (2.0 - 2.5HP) type designation 60245 IEC 57 or heavier cord.

- Installation work.
It may need two people to carry out the installation work.

- Do not install the unit in a place where leakage of flammable gas may occur. In case of gas leaks and accumulates at surrounding of the unit, it may cause fire.

CAUTION

- Do not install the unit in a place where leakage of flammable gas may occur.
Prevent liquid or vapor from entering sumps or sewers as vapor is heavier than air and may form suffocating atmospheres.

PRECAUTION FOR USING R32 REFRIGERANT

- Pay careful attention to the following precaution points and the installation work procedures.
WARNING: The appliance shall be stored, installed and operated in a well ventilated room with indoor floor area larger than 4m² (prefer Table A) and without any continuously operating ignition source.

- Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping.
Expansion and contraction of long runs piping in refrigerating systems shall be designed and installed securely.
Protect the refrigerating system from accidental rupture due to moving furniture or reconstruction activities.

CAUTION

- 1. General
Must ensure the installation of pipe-work shall be kept to a minimum.
Must ensure that pipe-work shall be protected from physical damage.
Must comply with national gas regulations, state municipal rules and legislation.

- 2-1. Qualification of workers
Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority.
2-2. Checks to the area
Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.

- 2-3. Work procedure
Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

- 2-4. General work area
All maintenance staff and others working in the local area shall be instructed and supervised on the nature of work being carried out.

- 2-5. Checking for presence of refrigerant
The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.

- 2-6. Presence of fire extinguisher
If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand.

- 2-7. No ignition sources
No person carrying out work in relation to a refrigerating system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition.

- 2-8. Ventilated area
Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.

- 2-9. Checks to the refrigerating equipment
Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.

- 2-10. Checks to electrical devices
Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.

- 3. Repairs to sealed components
During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers.

- 4. Repair to intrinsically safe components
Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

- 5. Cabling
Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.

- 6. Detection of flammable refrigerants
Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks.

- 7. Removal and evacuation
When breaking into the refrigerant circuit to make repairs - or for any other purpose - conventional procedures shall be used.

- 8. Charging procedures
In addition to conventional charging procedures, the following requirements shall be followed.

- 9. Decommissioning
Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.

- 10. Labelling
Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.

- 11. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 12. Labeling
The label shall be labelled and signed.

- 13. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 14. Labeling
The label shall be labelled and signed.

- 15. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 16. Labeling
The label shall be labelled and signed.

- 17. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 18. Labeling
The label shall be labelled and signed.

- 19. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 20. Labeling
The label shall be labelled and signed.

- 21. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 22. Labeling
The label shall be labelled and signed.

- 23. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 24. Labeling
The label shall be labelled and signed.

- 25. Recovery
When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

- 26. Labeling
The label shall be labelled and signed.

Attached accessories table with columns: No., Accessories part, Qty. Includes Drain elbow.

SELECT THE BEST LOCATION

- Outdoor Unit
If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
There should not be any animal or plant which could be affected by hot air discharged.

Table A: Capacity W (HP) vs Piping size (Gas/Liquid), Std. Length (m), Max. Elevation (m), Min. Piping Length (m), Max. Piping Length (m), Additional Refrigerant (g/m), Piping Length for add. gas (m), Max. Refrigerant Charge (kg), Indoor Area (m²).

** Systems with total refrigerant charge, m, lower than the 20kg are not subjected to any room area requirements. Example: For TZ20***

1 SELECT THE BEST LOCATION
(Refer to 'Select the best location' section)


2 INSTALL THE OUTDOOR UNIT

- After selecting the best location, start installation to Indoor/Outdoor Unit Installation Diagram.
Fix the unit on concrete or rigid frame firmly and horizontally by both nut (10 mm).

Table with columns: Model, A, B, C, D. Includes models TZ20, TZ25, TZ35, TZ42, TZ50, TZ60, TZ71.

3 CONNECT THE PIPING

- Connecting The Piping to Indoor
For connection joint location at outside building: Please make flare after inserting flare nut (locate at indoor portion of tube assembly) onto the copper pipe.




Connecting The Piping to Outdoor
Decide piping length and then cut by using pipe cutter.
Remove burrs from cut edge.

Table with columns: Piping size, Torque. Includes sizes 6.35 mm (1/4"), 9.52 mm (3/8"), 12.7 mm (1/2"), 15.88 mm (5/8"), 19.05 mm (3/4").

5 CONNECT THE CABLE TO THE OUTDOOR UNIT


- Remove the control board cover from the unit by loosening the screw.
Connect a cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 x 1.5 mm² (34 - 1.75HP) or 4 x 2.5 mm² (2.0 - 2.5HP) flexible cord.



WARNING: This equipment must be properly earthed.

DISPOSAL OF OUTDOOR UNIT DRAIN WATER

- If a drain elbow is used, the unit should be placed on a stand which is taller than 3 cm.
If the unit is used in an area where temperature falls below 0°C for 2 or 3 days in succession, it is recommended not to use a drain elbow.



IN CASE OF REUSING EXISTING REFRIGERANT PIPING

- Observe the followings to decide reusing the existing refrigerant piping.
Poor refrigerant piping could result in product failure.


6 PIPING INSULATION

- Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram.
If drain hoses or connecting pipes in the room (where dew may form), please increase the insulation by using POL-E FOAM with thickness 6 mm or above.



Proper Pump Down Method

- Operate air conditioner at cooling mode for 10 - 15 minutes.
After 10 - 15 minutes of pre operation, close 2 way valve.
After 3 minutes, close 3 way valve.



Most Important Process Purpose

- To make & refrigerant mix together.
To prevent refrigerant leak.
To prevent refrigerant from mixing with outdoor air.

CHECK ITEMS table with columns: Is there any gas leakage at flare nut connections?, Is the earth wire connection properly done?, Is the power supply voltage complied with rated value?, Is there any abnormal sound?, Is the cooling/heating operation normal?, Is the thermostat operation normal?.


A_min = (m_c / (2.5 x (LFL)^0.4 x h_v)) ^ 2

A_min = Required minimum room area, in m²
m_c = Refrigerant charge in appliance, in kg
LFL = Lower flammability limit (0.307 kg/m³)
h_v = Installation height of the appliance (1.8 m for wall mounted)

Required minimum room area, A_min, shall also be governed by the safety factor margin formula below:

A_min = m_c / (SF x LFL x h_v)

The higher value shall be taken when determining the room area.



It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.

This illustration is for explanation purposes only. Installation parts you should purchase (x).


OUTDOOR UNIT

AIR PURGING METHOD IS PROHIBITED FOR R32 SYSTEM

4 AIR TIGHTNESS TEST ON THE REFRIGERATING SYSTEM

- Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.
There is no extra refrigerant in the outdoor unit for air purging.


- Before system is charged with refrigerant and before the refrigerating system is put into operation, below site test procedure and acceptance criteria shall be verified by the certified technicians, and/or the installer.
Be sure to check whole system for gas leakage.



- Recommended use of any of the following leak detector,
I) Universal Sniffer leak detector
II) Electronic halogen leak detector
III) Ultrasonic Leak Detector

6 PIPING INSULATION

- Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram.
If drain hoses or connecting pipes in the room (where dew may form), please increase the insulation by using POL-E FOAM with thickness 6 mm or above.



Panasonic

Air conditioner

Installation Instruction

MODEL NO. :-
CS-TZ20, TZ25, TZ35, TZ42, TZ50, TZ60, TZ71WKE Series
CS-RZ20, RZ25, RZ35, RZ50WKE Series

Required tools for Installation Works

| | | | | | |
|--|---------------|---------------------|-------------------|---------------------|-------------------|
| 1 Phillips screw driver | 5 Spanner | 9 Gas leak detector | 13 Millimeter | 55 N•m (5.6 kgf•m) | 16 Gauge manifold |
| 2 Level | 6 Pipe cutter | 10 Measuring tape | 14 Torque wrench | 65 N•m (6.6 kgf•m) | |
| 3 Electric drill, hole core drill (ø70 mm) | 7 Reamer | 11 Thermometer | 18 Nm (1.8 kgf•m) | 100 Nm (10.2 kgf•m) | |
| 4 Hexagonal wrench (4 mm) | 8 Knife | 12 Megometer | 42 Nm (4.3 kgf•m) | 15 Vacuum pump | |

SAFETY PRECAUTIONS

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- This installation manual must be used together with another installation manual incorporated in applicable outdoor unit as complete full set of instructions.
- Confirm the type of gas used before installation.
- Electrical work must be installed by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

| | |
|----------------|---|
| WARNING | This indication shows the possibility of causing death or serious injury. |
| CAUTION | This indication shows the possibility of causing injury or damage to properties only. |

The items to be followed are classified by the symbols:
 Symbol with white background denotes item that is PROHIBITED.
 Symbol with dark background denotes item that must be carried out.

- Carry out test running to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

WARNING

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unit method or using incompatible material may cause product damage, burst and serious injury.
- Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit on veranda of a high rise building, child may climb up to outdoor unit and cross over the handrail causing an accident.
- Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.
- Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.
- Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.
- Do not sit or step on the unit, you may fall down accidentally.
- Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing.
- When installing or relocating air conditioner, do not let any substance other than the specified refrigerant, eg. air etc. mix into refrigeration cycle (piping). Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
- Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.
- Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.

- For R32/R410A model, use piping, flare nut and tools which is specified for R32/R410A refrigerant. Using of existing (R22) piping, flare nut and tools may cause abnormally high pressure in the refrigeration cycle (piping), and possibly result in explosion and injury.
- For R32 and R410A, the same flare nut and pipe can be used.
- Since the working pressure for R32/R410A is higher than that of refrigerant R22 model, replacing conventional piping and flare nuts on the outdoor unit side are recommended.
- If reuse piping is unavoidable, refer to instruction "IN CASE OF REUSING EXISTING REFRIGERANT PIPING".
- Thickness of copper pipes used with R32/R410A must be more than 0.8 mm. Never use copper pipes thinner than 0.8 mm.
- It is desirable that the amount of residual oil less than 40 mg/10 m.

- Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.
- For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.
- Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.
- Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
- For electrical work, follow the national regulation, legislation and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire.
- Do not use joint cable for indoor/outdoor connection cable. Use the specified indoor/outdoor connection cable, refer to instruction "CONNECT THE CABLE TO THE INDOOR UNIT and connect fitting for indoor/outdoor connection. Clamp the cable so that no external force will have impact on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.
- Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed properly, it will cause fire or electrical shock.
- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD), with sensitivity of 30mA at 0.1 sec or less. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.
- During installation, install the refrigerant piping properly before running the compressor. Operation of compressor without fixing refrigeration piping and valves at opened position will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
- During pump down operation, stop the compressor before removing the refrigeration piping. Removal of refrigeration piping while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
- Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.
- After completion of installation, confirm there is no leakage of refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire.
- Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when the refrigerant contacts with fire.
- Be aware that refrigerants may not contain an odour.
- This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.

- Do not install the unit in a place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.
- Prevent liquid or vapor from entering sumps or sewers since vapor is heavier than air and may form suffocating atmospheres.
- Do not release refrigerant during piping work for installation, re-installation and during repairing refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
- Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.
- Do not touch the sharp aluminium fin, sharp parts may cause injury.
- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.

- Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this air conditioner may increase the risk of rupture and this may result in less damage or injury and/or property.
- Power supply connection to the room air conditioner. Use power supply cord 3 x 1.5 mm² (3/4 - 1.75HP), 3 x 2.5 mm² (2.0 - 2.5HP) type designation 60245 IEC 57 or heavier cord. Connect the power supply cord of the air conditioner to the mains using one of the following methods.
- Power supply connection to the room air conditioner. Use power supply cord 3 x 1.5 mm² (3/4 - 1.75HP) or 3 x 2.5 mm² (2.0 - 2.5HP) type designation 60245 IEC 57 or heavier cord to the terminal board, and connect the other end of the cable to Isolating Devices (Disconnecting means).
- Power supply connection to the room air conditioner. Use an approved 15/16A (3/4 - 1.75HP), 16A (2.0 - 2.5HP), 20A (2.5HP) power plug with earth pin for the connection to the socket.
- Power supply connection to the room air conditioner. Use an approved 16A (3/4 - 1.75HP), 20A (2.5HP) circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.0 mm contact gap.
- Installation work may need two people to carry out the installation work.
- Keep any required ventilation openings clear of obstruction.

- Pay careful attention to the following precaution points and the installation work procedures.
- When connecting flare at indoor side, make sure that the flare connection is used only once. If torqued up and released, the flare must be remade. Once the flare connection was torqued up correctly and leak test was made, thoroughly clean and dry the surface to remove oil, dirt and grease by following instructions of silicone sealant. Apply neutral cure (Alkoxy type) & ammonia-free silicone sealant that is non-corrosive to copper & brass to the external of the flare connection to prevent the ingress of moisture on both the gas & liquid sides. (Moisture may cause freezing and premature failure of the connection)
- The appliance shall be installed in a well ventilated room with indoor floor area larger than A_{min} (m²) (refer Table A) and without any continuously operating ignition source. Keep away from open flames, any operating gas, any operating electrical device. Else, it may explode and cause injury or death.
- Refer to "PRECAUTION FOR USING R32 REFRIGERANT" in outdoor unit installation manual for other precautions that need to pay attention to.

PRECAUTION FOR USING R32 REFRIGERANT

Pay careful attention to the following precaution points and the installation work procedures.

When connecting flare at indoor side, make sure that the flare connection is used only once. If torqued up and released, the flare must be remade. Once the flare connection was torqued up correctly and leak test was made, thoroughly clean and dry the surface to remove oil, dirt and grease by following instructions of silicone sealant. Apply neutral cure (Alkoxy type) & ammonia-free silicone sealant that is non-corrosive to copper & brass to the external of the flare connection to prevent the ingress of moisture on both the gas & liquid sides. (Moisture may cause freezing and premature failure of the connection)

The appliance shall be installed in a well ventilated room with indoor floor area larger than A_{min} (m²) (refer Table A) and without any continuously operating ignition source. Keep away from open flames, any operating gas, any operating electrical device. Else, it may explode and cause injury or death.

Refer to "PRECAUTION FOR USING R32 REFRIGERANT" in outdoor unit installation manual for other precautions that need to pay attention to.

Attached accessories

| No. | Accessories part | Qty. | No. | Accessories part | Qty. | No. | Accessories part | Qty. |
|-----|---------------------------------|------|-----|------------------|------|-----|--|------|
| 1 | Installation plate | 1 | 3 | Remote control | 1 | 5 | Remote control holder | 1 |
| 2 | Installation plate fixing screw | 5 | 4 | Battery | 2 | 6 | Remote control holder fixing screw | 2 |
| | | | | | | 7 | Dust Collector Filter/Air Purifying Filter | 1 |




Table A

A_{min} = (m²) / (2.5 x LFL² x h) * 1000 ** not less than safety factor margin

| Model | Capacity (kW) | Max. Refrigerant Charge (kg) | Indoor Area (m ²) |
|------------------|---------------|------------------------------|-------------------------------|
| TZ20***, RZ20*** | 3.4HP | 0.82 | Not applicable (*) |
| TZ25***, RZ25*** | 1.0HP | 0.75 | Not applicable (*) |
| TZ35***, RZ35*** | 1.5HP | 0.85 | Not applicable (*) |
| TZ42***, RZ42*** | 1.75HP | 0.87 | Not applicable (*) |
| TZ50***, RZ50*** | 2.0HP | 1.33 | Not applicable (*) |
| TZ60***, RZ60*** | 2.5HP | 1.52 | Not applicable (*) |
| TZ71*** | 2.5HP | 1.82 | Not applicable (*) |

(*) Systems with total refrigerant charge, m², lower than 1.84kg are not subjected to any room area requirements.

** Table "A" only applicable for single split connection.


* In case of connection to outdoor multi inverter, refer to installation manual at outdoor unit.

INDOOR UNIT


1 SELECT THE BEST LOCATION

(Refer to "Select the best location" section)

2 HOW TO FIX INSTALLATION PLATE



| Model | ① | ② | ③ | ④ | ⑤ | ⑥ |
|---|--------|-----------|--------|--------|-------|--------|
| TZ20***, TZ25***, TZ35***, TZ42***, TZ50***, RZ20***, RZ25***, RZ35***, RZ50*** | 465 mm | 70 mm (+) | 365 mm | 415 mm | 60 mm | 120 mm |






| Model | ① | ② | ③ | ④ | ⑤ | ⑥ |
|------------------|--------|-------|--------|--------|--------|--------|
| TZ60***, TZ71*** | 605 mm | 80 mm | 550 mm | 550 mm | 270 mm | 320 mm |

- The center of installation plate should be at more than ① at right and left of the wall. The distance from installation plate edge to ceiling should more than ②.
 - From installation plate center to unit's left side is ③.
 - From installation plate center to unit's right side is ④.
 - For left side piping, piping connection for liquid should be about ⑤ from this line.
 - For left side piping, piping connection for gas should be about ⑥ from this line.
- Mount the installation plate on the wall with 5 screws or more (at least 5 screws). (If mounting the unit on the concrete wall, consider using anchor bolts.)
 - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
 - Drill the piping plate hole with ø70 mm hole-core drill.
 - Line according to the left and right side of the installation plate.
 - The meeting point of the extended line is the center of the hole.
 - Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely 115 mm (TZ20***, TZ25***, TZ35***, TZ42***, TZ50***, RZ20***, RZ25***, RZ35***, RZ50***) or 128 mm (TZ60***, TZ71***) for left and right hole respectively.
 - Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.


3 TO DRILL A HOLE IN THE WALL AND INSTALL A SLEEVE OF PIPING

- Insert the piping sleeve to the hole.
 - Fix the bushing to the sleeve.
 - Cut the sleeve until it extrudes about 15 mm from the wall.
- CAUTION**
When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.




4 INDOOR UNIT INSTALLATION


- Pull out the Indoor piping
- Do not turn over the unit without shock absorber during pull out the piping.
- It may cause intake grille damage.
- Use shock absorber during pull out the piping to protect the intake grille from damage.








- FOR THE RIGHT REAR PIPING
 - Step-1 Pull out the Indoor piping
 - Step-2 Install the Indoor Unit
 - Step-3 Secure the Indoor Unit
 - Step-4 Insert the power supply cord and connection cable



- FOR THE RIGHT AND RIGHT BOTTOM PIPING
 - Step-1 Pull out the Indoor piping
 - Step-2 Install the Indoor Unit
 - Step-3 Insert the power supply cord and connection cable
 - Step-4 Secure the Indoor Unit





- FOR THE EMBEDDED PIPING
 - Step-1 Change the drain hose position
 - Step-2 Bend the embedded piping
 - Step-3 Pull the connection cable into Indoor Unit
 - Step-4 Cut and flare the embedded piping
 - Step-5 Install the Indoor Unit
 - Step-6 Connect the piping
 - Step-7 Insulate and finish the piping
 - Step-8 Secure the Indoor Unit



CONNECT THE PIPING

- Connecting The Piping to Indoor
- Additional Precautions For R32 Models when connecting by flaring at indoor side
- Connecting The Piping to Outdoor
- Connecting The Piping to Outdoor Multi
- Gas side



| Outdoor Multi Combination Model | R32 Model | Pipe size (refer to diagram) |
|--|---|------------------------------|
| CS-TZ20***, CS-TZ25***, CS-TZ35***, CS-RZ20***, CS-RZ25***, CS-RZ35*** | CU-2235***, CU-2241***, CU-2250***, CU-3252***, CU-4258***, CU-5290***, CU-2124***, CU-2129***, CU-31252*** | ① |
| CS-TZ42***, CS-TZ50***, CS-RZ50*** | CU-2250***, CU-3268***, CU-4280***, CU-5290***, CU-21250***, CU-31252*** | ② (CZ-MA1P) |
| CS-TZ60***, CS-TZ71*** | CU-3268***, CU-4280***, CU-5290***, CU-21250***, CU-31252*** | ③ (CZ-MA2P) & ④ (CZ-MA3P) |

