



LinkRay – Quick Start Guide – ABB Terra





Remote Access

remote.versinetic.com/my-devices/login

Versinetic Remote Access
versatile ev charging solutions

Username:

Password:


[Sign in](#) [Forgot password?](#)

© 2023 by Versinetic

Step 1 – Remote access

Power on the LinkRay device with a wired network connection which has internet access.

Log onto the <https://www.remote.versinetic.com> with your supplied email and password.



Devices | Remote Access

remote.versinetic.com/my-devices/devices

Versinetic Remote Access > Devices

Devices Users Roles Domains Tenants System admin Sign out

021321012620202186 Show all devices Refresh Create device

Device / Description	Status	Public Device IP Address	Last Connected	Created	Domain
linkray-021321012620202186 Linkray Device #1	online	81.179.147.15	2024-06-24 18:04:39	2023-12-13 16:33:25	ad3063d1-dffd-4254-bb57-7ee317335a18

« Previous | Next » Page 1 of 1 (1 device total)


© 2023 by Versinetic

Step 2 – Select your device.

All devices on your account will be shown with their availability (on/offline).

Select the LinkRay name to connect.

Sites can be renamed here with the cog symbol



login

c9eebed5-8705-4763-8822-021a9efc7d6c.remote.versinetic.com

LINKRAY

Login

Username:

Password:

show password

Login

Type: LR
VPN IP: 10.8.0.52
Hostname: linkray-021321012620202186
Firmware Version: 1.3.7


Webapp 1.3.7

Versinetic 2024

Step 3 – Log in

Log into the LinkRay Device.

The default user / password is
Assembler /
2WW%[4%9nU`HWhGe



CSMS

CSMS Server Address

Identity

Allow New Charging While Offline Enabled

Site Configuration

Voltage [V] (L-N)

Split Mode (Line to Line) Disabled

Total Power [kW]

L1 [A]

L2 [A]

L3 [A]

Measurand Interval [s]

Line to Line Voltage (208V / 240V) 240V (Dual Phase)

FIFO Charging Mode Disabled

Use Meter Disabled

Step 4 – Configure the site power limits.

No CSMS URL (or the default ws://:80) means LinkRay is running without an internet backend for authorisation.

“Allow new charging while offline” indicates the LinkRay can authorise charging sessions itself (required when running in offline mode)

Site power is set to 100A on each of the three phases to the site in this example.

“Site meter disabled” means that the LinkRay will control charging limits without monitoring for additional power usage such as building power. In this mode ensure that the limits cannot be exceeded by lowering the total by a safe margin.


The screenshot shows the LinkRay web interface for network configuration. The left sidebar contains navigation options: Info, Chargers, Transactions, Configuration, Network (selected), Admin, Security, Debug, API, Assembler, Payment, and Logout. The main content area is titled 'Network' and is divided into 'Ethernet' and 'WiFi' sections. The 'Ethernet' section shows the network status as 'up', with 'DHCP' disabled and 'Static' selected. The IP address is set to 10.0.28.93/16, the gateway to 10.0.27.1, and the DNS server to 10.0.28.254. There are 'save' and 'reload' buttons. The 'WiFi' section shows the status as 'down', mode as 'normal', and an empty list of scanned networks with 'Refresh List' and 'Use as WiFi SSID' buttons. A 'Settings' button is located at the bottom of the page.

Step 5 – Network settings

Set a static IP address OR reserve the LinkRay IP in the routers DHCP lease.

Note after swapping between DHCP and Static the LinkRay may need to be rebooted.

This ensures that the IP address of LinkRay doesn't move, this is important as all chargers need to be configured to point to LinkRay.




Step 6 – Charger Configuration

Using the ABB Terra App log onto the charger using Bluetooth. You may be required to enter the user PIN at this point.

On the configuration page the default OCPP server will be ABB, click this to update.

On the OCPP server page enable the external server slider.



Step 7 – Charger Configuration (Continued)

Select the “add and configure custom server”

Enter the IP address of the LinkRay device from the Network page on LinkRay, this should be in the format of


`ws://aaa.bbb.ccc.ddd:8887`
or

`wss://aaa.bbb.ccc.ddd:8886`

`ws` indicated a web socket (like http)

`wss` indicated secure web sockets (like https)

Confirm, save, and apply the configuration, you will see the settings being saved, check this completes successfully.



The screenshot shows the LinkRay web interface. The top navigation bar includes 'LINKRAY' and a sidebar menu with options: Info, Chargers, Transactions, Configuration, Network, Admin, Security, Debug, API, Assembler, Payment, and Logout. The main content area displays system status metrics and a table of charge stations.

System Status Metrics:

L1 [A]	L2 [A]	L3 [A]	Voltage [V]	L1 [A]	L2 [A]	L3 [A]
0.00	0.00	0.00	240.000	200.00	6.00	6.00
Total Power [kW]			Total Power [kW]	L1 [kW]	L2 [kW]	L3 [kW]
0.00			50.88	48.00	1.44	1.44

Charge Stations (Licenses in Use: 1 / 8)

Auto-Refresh:


<input type="checkbox"/>	charger name	high priority	connector id	transaction id	offered [A]	power [kW]	L1 [A]	L2 [A]	L3 [A]	measurands	status	controls
<input type="checkbox"/>	Paul	Limit: 50A			0.00	0.00	0.00	0.00	0.00			
<input type="checkbox"/>	TONY	Limit: 100A			0.00	0.00	0.00	0.00	0.00			
<input type="checkbox"/>	Trevor	Limit: 20A			0.00	0.00	0.00	0.00	0.00			
<input type="checkbox"/>	Unassigned				0.00	0.00	0.00	0.00	0.00			
<input type="checkbox"/>	TACW2243320T0723	<input type="checkbox"/>	1	0	--	0.00	0.00	0.00	0.00	<input type="checkbox"/>	idle available	start

Buttons: Balanced, Delete, Refresh

Footer: Webapp 1.3.7

Step 7 – LinkRay Info

After the ABB Terra has rebooted with the new configuration you will see the TACWxxxx device appear in the Charge Stations, it should indicate it is idle and available.



LINKRAY

Info

Chargers

Transactions

Configuration

Network

Admin

Security

Debug

API

Assembler

Payment

Logout

Webapp 1.3.7

Charger Settings

Chargers

<input type="checkbox"/>	Charger Name	Friendly Name	Single/Three Phase	Phase Connection	Max power per charger in A (Per Phase) or W (Total)	Max-Charge Rate Unit	Group
<input type="checkbox"/>	TACW2243320T0723	Bay1	3	L1-L2-L3	32	A (Amps)	unassigned



Save

Batch Update

Selected Chargers	Single/Three Phase	Phase Connection	Max power per charger in A (Per Phase) or W (Total)	Max Charge Rate Unit	Group
	unchanged	unchanged	unchanged	unchanged	

Apply

Groups

Group Name	Limit	Number of Chargers	Chargers	Remove
Paul	50	0		
TONY	100	0		

Step 8 – Charger Configuration


Select the Charger page.

Enter a friendly name to aid identifying devices.

Select if the charger is single or three phase and its physical phase connection.

(optionally) Chargers can be grouped with limits per group if required.

Click on Save.



LINKRAY

Info

Chargers

Transactions

Configuration

Network

Admin

Security

Debug

API

Assembler

Payment

Logout

Webapp 1.3.7

Versinetic 2024

Transactions

c9eebed5-8705-4763-8822-021a9efc7d6c.remote.versinetic.com/Transactions/

Recent Transactions

No Transactions Found

Toggle All Download Selected Transactions Download NEM12 Logs

RFIDS Rejected

No RFIDS Rejected

Whitelisted RFIDS (disabled)

Enable Disable

No Whitelisted RFIDS found

+

Whitelist Import / Export

Choose Whitelist File... Browse Import Whitelist Export Whitelist

Step 9 – Enable and add any RFID tags (optional)

If required turn on a whitelist for RFID authorisation.

Add tags by presenting them to a configured charger, entering using a CSV file or manually using the [+] button.

Step 10 – Test

Navigate to the Info screen, and perform a test charge,

Full user manuals are available at <https://docs.versinetic.com>