

Instruction manual



**Unitor Welding Inverter
UWI 500 TP & UWF 102
MMA, ACA, TIG and Wire welding**

CONTENTS

SECTION	PAGE
1. GENERAL DESCRIPTION	3
2. TECHNICAL DATA	4
3. INSTALLATION	7
4. FRONT PANEL CONTROLS	8
5. STICK ELECTRODE WELDING	10
6. AIR CARBON ARC GOUGING	11
7. TIG WELDING	12
8. WIRE WELDING	13
9. ROUTINE MAINTENANCE	18
10. TROUBLESHOOTING	19
11. ORDERING INFORMATION MACHINES	21
12. ORDERING INFORMATION BASIC ACCESSORIES	22
13. TIG AND WIRE TORCHES WITH SPARES	23
14. WIRING DIAGRAM UWI-500TP	26
15. COMPONENTS AND SPARES UWI-500TP	28
16. COMPONENTS AND SPARES UWF-102	30
17. WIRING DIAGRAM FOR UWF-102	32
18. SAFETY INSTRUCTIONS	33
19. NOTES	37
20. UNITOR HANDBOOK FOR MARITIME WELDERS	39

DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS
MANUAL INCLUDING THE SAFETY INSTRUCTIONS

1 GENERAL DESCRIPTION UWI-500TP

Automatic adjustment to any primary voltage between 380 and 440V.

Line Voltage compensation keeps output of the power source constant regardless of fluctuation in input power from 10% below lowest to above highest rated input voltage.

Safe in use. Touchable open circuit voltage only 9V, providing optimal safety for the operator

Adjustable Hot Start for MMA provides optimal arc striking for all electrode types and prevents electrode sticking.

Adjustable Arc Force for stick electrode welding allows the arc characteristics to be changed for specific applications and electrodes.

Lift-Start in TIG mode provides easy and soft TIG arc start and remote control from 5 amp to max. ensures total arc control both during welding and for the down-slope finish of the weld.

Casing of high-grade aluminium and industrial plastic to eliminate corrosion damage also contributes to low weight, which together with compact outer dimensions provides good portability.

Wind tunnel design for the internal cooling airflow protects electrical components and PC boards from dirt, dust, debris, greatly improving reliability.

Thermal overload protection with indicator lights helps prevent machine damage if the duty cycle is exceeded or airflow is blocked.

Total Protection function with indicator light prevents machine damage if one phase in the primary power supply falls out or if over-voltage is supplied to the machine.






















Separate characteristics for welding with standard electrodes, for cellulosic electrodes, for TIG, for Air Carbon Arc gouging and for Wire welding with or without shielding gas ensures optimal properties for all processes








The remote amperage control can be used for all processes, and also for two machines in parallel for up to 1000 Amp. for Air Carbon Arc gouging.




Delivered as machine only, with primary cable (correct plug must be added) and instruction manual

2 TECHNICAL DATA

UNITOR		Wilhelmsen Ship Service AS Strandveien 20 - P O Box 33 N-1324 Lysaker NORWAY			
Model: UWI-500TP					
Product number:					
3~ 		EN 60974-1 EN 60974-10 Class A			
		5A/20.2V		500A/40.0V	
		X	50%	60%	100%
		$U_0=66V$	I_2	500A	450A 400A
		$U_r=9V$	U_2	40.0V	38.0V 36.4V
		5A/10.2V		500A/30.0V	
		X	50%	60%	100%
		$U_0=66V$	I_2	500A	460A 400A
		$U_r=9V$	U_2	30.0V	28.4V 26.0V
		5A/14.2V		500A/39.0V	
		X	50%	60%	100%
		$U_0=66V$	I_2	500A	450A 400A
		$U_r=9V$	U_2	39.0V	36.5V 34.0V
	3~ 50 / 60Hz			I_{1max}	I_{1eff}
		$U_1=440V$		36.3A	27.4A
		$U_1=400V$		38.2A	29.5A
		$U_1=380V$		40.7A	30.5A
COOLING AF		I.C.L.H.	IP 23S		
					
 WARNING: EXTERNAL FUSE					
					
			T 2A 500V		

UNITOR		Wilhelmsen Ship Service AS Strandveien 20 - P O Box 33 N-1324 Lysaker NORWAY	
Model: UWF-102			
S.n:			
EN 60974-5		EN 60974-10 Class A	
	$U_1=48V$ $1\sim 50/60Hz$	$I_1=1.5A$	
		IP 23	
 1.5-18m/min	$I_2=450A/60\%$	$I_2=400A/100\%$	
			
 RoHS			

Type of welding machine



Three-phase static transformer rectifier with frequency converter and DC output.

Standards

EN 60974-10 European Norm for electromagnetic compatibility.

EN 60974-1 European Norm for arc welding appliance: Current sources for welding.

Processes



MMA (Manual Metal Arc welding (stick electrode welding))



TIG Tungsten Inert Gas welding




MIG/MAG Metal Inert/Active Gas shielded welding (wire welding)

Safety Marking



Suitable for use in areas with increased electric shock hazard

X: Duty cycle



Duty Cycle is the percentage of 10 minutes that the unit can weld at rated load without overheating. It refers to a 40°C environmental temperature. If the unit overheats a thermal switch stops the output, the warning light for over-temperature is lit and the cooling fan continues to run. Wait until the warning light darkens, then reduce amperage or duty cycle before continuing to weld.

I₂ = Welding current.

Range 5 – 500A cover a range from the most small scale thin plate TIG welding to groove preparations with chamfering electrodes and all normal Air Carbon Arc Gouging. Parallel connection ability doubles the range.

U_r = No-load voltage

Is the voltage between welding terminals (touchable voltage) when the machine is idle and equipped with a voltage reduction function for operator safety. Low value means high operator safety, and with this in mind this machine satisfies the world's strictest regulation: AS 1674.2-2007 Safety in welding and allied processes (Australian standard) which allows for maximum 35V.

Note: Mean value measured according to IEC 60974-1 is used in AS 1674.2 and is 9V for UWI-500TP. This will show up as 12,7V on display 6 when V is selected as this instrument displays peak value, not mean value.

U₀ = Arc striking voltage

When electrode touches work piece the U_r voltage will within a split second jump to this value. It is important that this value is high enough to enable quick and easy arc start for all welding consumables.


U₂ = Arc voltage

This is the voltage present between the output outlets when welding is being carried out, in relation to a particular set welding current.

The relation between voltage and amperage for the various welding modes are the following:

MMA	→ $U_2 = 20 + 0,04 \cdot I_2$
TIG	→ $U_2 = 10 + 0,04 \cdot I_2$
MIG/MAG	→ $U_2 = 14 + 0,05 \cdot I_2$

Primary connection



- U_1 = Effective input voltage which must be between 380 and 440V
 I_{1max} = Maximum value of input current at the corresponding duty cycle.
 I_{1eff} = Effective value of input current at the corresponding duty cycle.
Maximum input power is 26,5 kVA. Power factor 0,85. Duty Cycle 50%

32A slow fuses will be the right fuse size for this machine.

NOTE:

If two machines are to be used in parallel for up to 1000 amp output each machine needs a separate 32 Amp connection.

Cooling

COOLING AF= Forced air cooling (with a fan).

NOTE:

This cooling requires sufficient space to allow free air flow for cooling, a minimum of 50 cm on all sides is recommended,

Protection class

IP23S= Ingress Protection class. Protection degree of the casing according to EN 60529
2: Protection against object 80mm in length and more than 12mm in diameter
3: Protection from sprayed water at an angle of 60° from vertical
S: Valid at standstill. (Can be used outdoors but not in heavy wind and rain)

NOTE:

Equipment with lower IP class should not be used outdoors.

Thermal insulation class

I.CL.H= Thermal class of the insulating materials and insulation systems.
Class H: resistant up to 180°C.

Conformity to the rules of the European Union



Mark stating conformity to all safety standards and other standards required for sale and use within the European Union.

Recast Directive



This mark confirms that the product conforms to the RoHS directive which restricts the use of specific hazardous or restricted substances in electrical and electronic equipment put on the market in the European Union.

Restricted substances are: 1. Lead (0.1%) 2. Mercury (0.1%) 3. Cadmium (0.01%) 4. Hexavalent chromium (0.1%) 5. Polybrominated biphenyls (0.1%) 6. Polybrominated diphenyl ethers (PBDE) (0.1%)

3 INSTALLATION

Only qualified personnel should perform this installation.

Only personnel that have read and understood this Manual should install and operate this equipment.

Machine must only be plugged into a receptacle which is grounded in accordance with valid regulations.

Note

The power switch should be in the OFF position when installing work cable and electrode cable and when connecting power cord to input power.

Dimensions and weight

	UWI-500	UWF-102
Height	: 510mm	440mm
Length	: 670mm	690mm
Width	: 290mm	385mm
Weight	: 47kg	17,4kg



Select suitable location

UWI 500TP and UWF-102 have IP23S rating.

Locate UWI-500TP in a dry location where there is free circulation of clean air into the louvers in the back and out the front of the unit. Ensure minimum 50cm free space on all sides. If free flow of air is hindered the machine will overheat.

A location that minimizes the amount of smoke and dirt drawn into the louvers reduces the chance of dirt accumulation that can block air passages and cause overheating.

The UWF-102 has no air cooling.

Avoid tilting


The machine must be placed on a secure, level surface, maximum 15° out of horizontal.

Rear panel functions


- 1: Primary cable. Mount plug and connect to socket with 32A slow fuses
- 2: On/Off switch
- 3: When lit the Total Protection function has been activated due to one missing phase in the power supply. Switch machine off, and correct the power supply before continuing.
- 4: Remote control connection.
Note: If remote control is connected it must be activated by selecting remote control on the front panel
- 5: Power supply transformer fuse, slow, 530mA, 500V
- 6: Control cable to wire feeder (at the bottom)



4 FRONT PANEL CONTROLS




Select process (1)



- Normal stick electrodes
- Cellulosic stick electrodes
- Air Carbon Arc Gouging
- TIG welding

← Press button until light for the process is on. No light for wire welding

Select remote control (2)



Control from wire feeder: The wire feeder must be connected to the back panel bottom section
Remote control for electrode holder or TIG torch: Connect to the machine back panel top section

← Press button to turn light for remote control on.

Keep depressed for 3 seconds to activate control from wire feeder.

The display will then show the message: "---"

No light means front panel control

Arc force (3)

Arc force increases the short circuit amperage providing a crisper arc, allowing the welder to use very short arc without sticking the electrode in the melt pool. It is useful when welding with stick electrodes at low amperages but gives more spatter. Set control to 0 (soft arc) for normal electrode welding and TIG welding.

Hot start (4)

Hot start increases the start current for 0,4 seconds: It makes arc striking easier and reduces the possibility for electrode sticking. With setting for normal stick electrodes the increase can be adjusted from 0-100% of set current. For cellulosic stick electrodes the increase is up to 200%

Warning lights (5)



Power on warning. Green light when there is power to the +/- sockets.

Alarm light, see display for further information



Display message: AL.H

The machine has overheated, the fan continues to run, all other functions are disabled. Check first if the Total Protection LED is ON, if not check that the cooling air is unhindered and flows freely through the machine.

When the machine has cooled down power will automatically be restored.

Reduce output power setting or operate at a lower duty cycle to avoid repetition



Display message: E.69

There is a fault in the wire feeder software, the fan continues to run, all other functions are disabled. Disconnect the wire feeder and send it for service.

When another process is selected the machine will function normally.

Display setting (6)



← Select button


Select A

The display will show the welding current which is set with adjustment knob (7)

Select V

The display will show no-load voltage when not welding, and arc voltage during welding

5 STICK ELECTRODE WELDING




Select top setting, MMA welding for normal stick electrodes

Select setting CEL for optimal welding characteristic for cellulosic electrodes.

Connect return (ground) cable with good contact directly to the work piece.

Select polarity and amperage as recommended for the electrode and start the arc as follows:



Drag electrode across work piece like striking a match and lift electrode slightly after touching work. If arc goes out the electrode was lifted too high or the hot start setting is too low.

If electrode sticks to work piece, use a quick twist to free it before it becomes too warm. If that is difficult switch off the machine or disconnect the electrode holder from the electrode before restart

Hot start

Setting right level for hot start makes arc striking easier and reduces the possibility of electrode sticking. If arc start is difficult the hot start setting should be increased until the arc starts satisfactory.


Arc Force

Use no or low Arc Force setting for smooth running electrodes like LH and SPECIAL.

Increased setting provides optimal characteristics for stiffer, more penetrating electrodes like E6010 types, chamfering electrodes like CH2 and electrodes for ACA gouging.

Increased arc force may also be an advantage in position welding

6 AIR CARBON ARC GOUGING



Select maximum Hot start and Arc force.

Connect electrode holder to plus (+) polarity.

Connect return (ground) cable to negative (-) polarity with good contact directly to the work piece.

If possible bring machine to the work place with a primary cable extension instead of welding cable extensions.


If welding cable extensions are required 95mm² is recommended.

Set correct amperage for the selected electrode size

For larger electrodes than 8mm more than 500A may be required. Two machines may then be used in parallel as follows:

- Set both machines to identical parameters with ACA as selected process and with maximum Hot start and Arc force
- Set both machines to remote control and if extensions are necessary use same length remote control cables from each machine to the work site where the remote control parallel connection kit, product number **676973**, is used to connect both machines to the same remote control
- If remote control is not used both machines should be set to the same ampere value on the displays, half of the required value for the electrode
- Return cables from both machines should be of equal length and clamps should be connected close together directly on a clean part of the work-piece. 95mm² cable is recommended.
- Welding cables from both machines must be of equal length to the work site where the parallel connecting three-way connector DIX70 male-female-female, product number **632901** is used to connect both machines to the same Air Carbon Arc torch (product number **528703**) . A connector conversion is required here, product number **634121**.

7 TIG (GTAW) WELDING



← TIG welding

Select TIG process and connect the TIG torch to the regulator with flow control. The torch should have gas valve on the handle.

Connect TIG torch to the negative (-) terminal of the machine.

Connect return (ground) cable with good contact directly to the work piece.

Avoid long welding cable extensions if possible.


Use remote control attached to the torch

With the TIG process normal open-circuit voltage is not present before tungsten electrode touches and lifts from work piece. Only a low sensing voltage is present between electrode and work piece.


The solid-state output contactor does not energize until after electrode is touching work piece. This allows the electrode to touch the work piece without overheating, sticking, getting contaminated or contaminate the work piece.

Start the arc as follows:


- Turn gas on.
- Touch tungsten electrode to workpiece at weld start point.
- Hold electrode to workpiece for maximum 1-2 seconds, and slowly lift electrode. This may be done by tilting the electrode holder sideways until the gas nozzle touches the work piece and the electrode is lifted.
- The arc is formed when the electrode is lifted.



1 Electrode
2 Workpiece



Touch the electrode to the work piece. Only sensing voltage will be present



Lift carefully and the arc will be established

During welding the operator has continuous control of amperage and arc with the remote control on the torch.

Stop the arc as follows:

- Slope down welding current at convenient speed until arc stops
- Hold the torch over the finishing point for a short while to provide gas shield and avoid oxidation.
- Close off gas flow

8 WIRE WELDING (MIG/MAG, GMAW, FCAW)

The wire feeder UWF-102 Air is a wire feeder specially developed for the multi-process welding power source UWI-500TP.

By connecting UWF-102 to UWI-500TP it is, in addition to wire welding, also possible to do stick electrode welding and Air Carbon Arc gouging from the wire feeder without reconnecting



Connecting UWF-102 to UWI-500TP and shielding gas

The wire feeder is delivered with the required hoses and cables for connection to shielding gas and UWI-500TP

4m gas hose for shielding gas is connected here:
The other end has nut with 3/8" RH threads for connection to a shielding gas regulator on a gas cylinder

4m remote control cable for connection to the back side of UWI-500TP is connected here:

The 4m connection cable for welding current is connected here:



NOTE:

Correct polarity for the welding process must be selected when connecting the welding cables to correct polarity for welding and return at the power source.
If cable extensions are used the return cable should also be extended to the work place for polarity selection there.

The welding cable should always be connected to the + or – terminals on the front panel of UWI-500TP to ensure that correct polarity for the wire is used is used.

Positive + polarity is normally used for gas-shielded wires


Negative – polarity is normally used for self-shielded wires




The 4m remote control cable from UWF-102 is connected at the back of the UWI-500TP here:

Select control of UWI-500TP from UWF-102 with the selection knob 2 on the front panel of UWI-500, see section 4

Front panel controls



Select process (1)



- ← Wire welding (MIG / MAG / FCAW)
- ← Coated electrodes, (not cellulosic)
- ← Air Carbon Arc gouging

Select button



Wire welding torch connection
Stick electrode holder and ACA torch connection

For Stick electrodes:

Select + or – according to electrode specification and connect this polarity from the welding machine to the back of the wire feeder. The other polarity is return cable from workpiece to welding machine

For ACA gouging:

Connect to + polarity from the welding machine to the back of the wire feeder. The - polarity is return cable from workpiece to welding machine


Set welding current on potentiometer 5. Display 7 will show the set welding current in Amperes when electrode welding or Air Carbon Arc gouging is selected

Select wire welding process



Connect proper polarity for the wire from the front of the welding machine to the back of the wire feeder, and the return cable from the work-piece to the welding machine

Select trigger function (2)



← 2-stroke function. Press trigger to start wire feed and welding, and keep trigger pressed. Release trigger to stop wire feed and welding.

← 4-stroke function. Press and release trigger to start wire feed and welding, then Press and release trigger to stop wire feed and welding.

2-stroke is used for shorter welds, 4-stroke is used for long continuous welds so that the welder does not have to keep the trigger pressed through the whole welding sequence

Set shielding gas flow and post gas time (3)




Connect shielding gas from gas cylinder flow regulator to the back of the wire feeder and open for gas.

Press and release this button and the gas valve in the wire feeder will open for 15 seconds to allow adjustment of correct flow on the cylinder regulator.

Press again for 2 seconds and the letters P.G. will appear on Display 7 and gas post flow in seconds will appear on Display 8. Adjust post flow time with potmeter 6 if required, then press again to store the value.

Cold wire feed (4)



When wire spool is properly inserted and drive rolls closed this button is pressed to feed the wire through to the torch without voltage / welding current present, and without shielding gas flow.

Set wire feed speed (5)

Set wire feed speed on potmeter 5. Display 7 will show the set wire speed in m/min when wire welding is selected

Set welding voltage (6)

Set wire feed speed on potmeter 6. Display 8 will show the set voltage when wire welding is selected

Adjust inductance (12)

When welding with a short arc lower inductance will give crisper arc and easier arc start. The bead will become taller and narrower.

More inductance will give a softer arc and flatter wider bead appearance. Too much inductance will give difficult arc starts.


Low thermal conductivity materials like stainless steel need more inductance to get acceptable wetting with short arc.

Warning signals


9: The welding machine has overheated and needs cooling
See ch.4:5

10: "HOLD": The displays 7 and 8 show last real measured values. The light will go out when welding starts again and real values will be shown

11: When lit this light informs that power is available at the wire feeder terminals



Display 8 warning messages



Remote control from wire feeder has not been selected on the welding machine, see ch.4:2

When communication between welding machine and wire feeder does not function properly message Err.C0, Err.C11 or Err.C12 will be displayed.

The welding machine has overheated and needs cooling. This message will be displayed together with warning light 1. See ch.4:5

Spool box and wire feed compartment

UWF 102 wire feeder has a separate spool box outside The wire feed compartment. The spool box is angled slightly upwards for operator ease of use, and facilitates all standard spool sizes.


Spool box lid

Note: Keep closed when welding, the wire will then be Electrically live.

Spool box

Shaft for wire spool


Locking cap for shaft



Locking stud.
Fits corresponding hole in spool and prevents spool from sliding on the shaft

Friction brake adjustment.

Correctly set the brake will stop the spool at the instant welding stops to prevent wire from unwinding from the spool, but not hold back so much that smooth wire feeding is prevented



Wire feed system with drive rolls and adjustment of the drive roll pressure in the wire, see next page.

Wire loading


Pull the pressure arm **(1)** outwards to release the spring loaded wire feed drive rolls **(2)**.

Check that correct wire feed drive rolls for the wire is installed with correct groove size in position (see next section), if not unscrew the fixing caps **(3+4)** and turn rolls or replace with correct rolls.

Place the wire spool in place on the wire spool spindle. Make sure that the locking stud engages in the corresponding hole in the wire spool.

Carefully detach the end of the wire from the spool, cut the bent portion of wire off and straighten the first 10cm.

Thread the wire through the ingoing guide tube **(5)**, over the drive roll **(3)**, through the intermediate guide **(6)**, over the drive roll **(4)** and into the outgoing guide tube **(7)**. This guide tube starts very close to drive roll **(4)** and reaches through the torch connector to the torch




Close the wire feed drive rolls **(2)** and latch the spring loaded pressure arm **(1)** in place. The roll pressure on the wire is adjusted with the screw on the pressure arm. It should be tightened sufficiently to ensure smooth feeding of the wire and still slide on the wire if the wire is stopped by a blocked torch nozzle




Drive rolls

V-groove smooth drive rolls are used for all solid vires except aluminum.












U-groove drive rolls prevents deformation and is specially designed for Aluminum which is soft and will be deformed when sufficient pressure for smooth feeding is applied towards a V-groove drive roll, resulting in poor welding results.

Knurled V-groove drive rolls are specially developed for flux-cored wires and provides excellent grip on the hard surface of these wires without requiring a pressure that will deform these tubular wires.



V-groove		Knurled groove		U-groove	
					
Size	Order no	Size	Order no	Size	Order no
0,8 - 1,0mm	778192	0,8 - 1,0mm	778195	0,8 - 1,0mm	778197
1,2 - 1,6mm	778194	1,2 - 1,6mm	778196	1,2 - 1,6mm	778198

9 ROUTINE MAINTENANCE

Checkpoint		Action	Interval
Primary plug and socket		Check connections and stretch relief	3 months or more often if needed
Primary cable		Check for damage and replace if necessary	3 months or more often if needed
Primary cable stretch relief and connection		Check for damage and tightness	3 months or more often if needed
Labels		Replace damaged or unreadable labels	3 months or more often if needed
Internal dust and dirt		Blow out or vacuum inside	6 months or more often if needed
Welding current sockets		Check and clean	3 months or more often if needed
Cable connectors		Check, clean if needed and tighten	Prior to use / every 3 months
Welding cables		Repair or replace if damaged	Prior to use / every 3 months
Electrode holders and torches		Check, clean and replace if damaged	Prior to use / every 3 months
Ground clamps		Check tightness and clean contact points	Prior to use / every 3 months
Remote controls, if relevant.		Check function and condition of cables	3 months or more often if needed

10 TROUBLESHOOTING

SYMPTOM	POSSIBLE REASON	SOLUTION
No output, no warning light, fan not running	Primary power does not reach the machine	Mains fuses blown
		Machine is not plugged in
		Broken primary cable
		Cable connection to machine is loose
		Machine not switched on
		On/off switch damaged
No output, yellow warning light	One phase is missing in primary power supply	Check the supply power from the vessel for blown fuses, loose connections etc.
	Thermal protection activated	Used at too high duty cycle, wait until machine has cooled down and power returns. Weld with more breaks or lower current
		Cooling air flow is hindered, remove obstructions
		Heat development in loose electrode holder or ground cable connections
		Broken fan, repair or replace
		Too much dirt in power source compartment, clean.
No arc, no warning light	Incomplete circuit	Check ground cable and torch connections.
Unstable arc	Polarity	Check that polarity on the machine matches the wire
	Poor contact	Check ground clamp and torch connections
	Unclean work piece	Clean

RESETTING SOFTWARE

Unidentified software problems may prevent the welding power source from functioning correctly.

If normal troubleshooting does not help the below software reset procedure should be used.

The reset procedure involves complete restoration of the default values, parameters and memory settings to original values.

UWI-500TP

-Switch the welding machine off.

-While pressing buttons A and B switch the machine on.

-Release buttons A and B.

The message **REC** will appear on the display.
When the message disappears the machine is ready

UWF-102



-Switch the welding machine off and connect the wire feeder.

-While pressing buttons C and D switch the machine on.

-Release buttons C and D.

The message **rEC FAC** will appear on the displays of the wire feeder.

When the message disappears the machine is ready



11 ORDERING INFORMATION MACHINES



UWI-500TP Multi process welding inverter Order no 191-500500



Undercarriage for UWI-500TP Order no 196-500103

Spare part kit for UWI-500TP includes power board, necessary additional components and complete instructions for replacement Order no 191-500505



UWF-102 Wire Feeder for UWI-500TP Order no 191-500102

12 ORDERING INFORMATION BASIC ACCESSORIES

Basic accessories	
Basic accessories kit for UWI-500TP	196 670406
Consisting of: (Order numbers to be used when re-ordering)	
Flip-Vision shield with flip-up frame, head band and filter shade 11 glass	196 709485
Long lined welding gloves, 1pair (re-ordering number is for 6 pairs)	196 632786
Electrode holder with 3m cable and connector	196 594325
Ground clamp with 3m cable and connector	196 594317
Wire brush, steel, 2 rows, 1 pcs (re-ordering number is for 6 pcs)	196 632 976
Chipping hammer steel, 1 pcs (re-ordering number is for 2pcs)	196 633008
Remote control with 8m cable	191 670414
Air Carbon Arc gouging accessories	
ACA-torch 600A with cable & safety connector, air hose & quick connector	196 528703
Cable connector conversion, safety connector to DIX for UWI connection	195 634121
Shielding gas supply	
Argon regulator with flow adjustment 0-32 l/min	197 510010
Flow control meter for use at torch nozzle	197 597328
Flow control needle valve for gas flow adjustment	197 597310
TIG welding Accessories	
Specially thin and soft TIG gloves, 6 pairs	197 632794
TIG-torch T-200 with gas valve and DIX 70 connector	197 200000
Accessories kit for TIG-torch	197 607810
Wire welding Accessories	
Torch for gas shielded wire welding	193 607451
Torch for gasless wire welding	193 750179
Special pliers for wire welding	193 591990
Anti-spatter spray for nozzle protection	193 633149
Flow-control meter for use at torch nozzle	197 597328
Shielding gasses	
Argon and Argon/CO ₂ 80/20 is available in 10 l cylinders and 50 l cylinders. Pure CO ₂ is available on request	

13 TIG AND WIRE TORCHES WITH SPARES

TIG torch T-200 complete with long back-cap, 2,4mm electrode, collet and nozzle
Order number 197-200000



Pos.	Order number	Unit	Product description
1	197-551192	pcs	Short back-cap
2	197-551200	pcs	Long back-cap
3	197-613767	pcs	Heat shield
4	197-551168	pcs	Collet 1.6mm
4	197-551150	pcs	Collet 2.4mm
5	197-551184	pcs	Collet body 1.6 mm
5	197-551176	pcs	Collet body 2.4 mm
6	197-551135	pcs	Alumina nozzle 6
6	197-551127	pcs	Alumina nozzle 7
7	197-674710	pck	Tungsten electrode (10 pcs) 1.6 mm alloyed for DC welding
7	197-674736	pck	Tungsten electrode (10 pcs) 2.4 mm alloyed for DC welding

T-400 torch for gas shielded wire welding, complete with contact tip 1,0-1,2mm and Teflon liner. Order number 193-607451




Pos.	Order number	Unit	Product description
1	193-551192	pcs	Gas nozzle for torch
2	193-613766	set	Nozzle insulator 5 pcs
3	193-594622	set	Contact tips 0,6-0.8 mm 10 pcs
3	193-594630	set	Contact tips 1,0-1,2 mm 10 pcs
3	193-607455	set	Contact tips 1,2-1,4 mm 10 pcs
3	193-607456	set	Contact tips 1,6-2,0 mm 10 pcs
4	193-613763	set	Gas diffusor 5 pcs
5	193-613764	set	Neck insulation 5 pcs
6	193-594606	pcs	Torch liner, Teflon for 0.6-1.2 mm wire 4.5 m long
6	193-594614	pcs	Torch liner, Steel for 0.6-1.0 mm wire (blue) 3.0 m long
6	193-607457	pcs	Torch liner, Steel for 1.0-1,4 mm wire (red) 3.0 m long
6	193-777846	pcs	Torch liner, Steel for 1,4-1,6 mm wire (yellow) 3.0 m long


T-350 torch for gasless welding with self-shielded wire, complete with 1,6mm contact tip and 1,4-1,6mm steel liner. Order number 193-750179




Pos.	Order number	Unit	Product description
1	n.a.	n.a	End of swan neck on torch
2	193-594614	pcs	Torch liner, Steel for 0.6-1.0 mm wire (blue) 3.0 m long
2	193-607457	pcs	Torch liner, Steel for 1.0-1,4 mm wire (red) 3.0 m long
2	193-777846	pcs	Torch liner, Steel for 1,4-1,6 mm wire (yellow) 3.0 m long
3	193-750185	pcs	Tip adaptor for torch
4	193-750181	set	Contact tips 1,0 mm 10 pcs
4	193-750182	set	Contact tips 1,6 mm 10 pcs
5	193-750184	pcs	Ceramic nozzle for torch

14 WIRING DIAGRAM UWI-500TP





15 COMPONENTS AND SPARES UWI-500TP




N°	CODE	DESCRIPTION
1	040.0003.1002	TERMAL SWITCH L=200mm
2	040.0003.0060	TERMAL SWITCH
3	011.0013.0009	LATERAL PLATE
4	050.5308.2400	LOGIC FRONT PANEL 500
5	014.0002.0009	KNOB
6	014.0002.0017	KNOB
7	011.0013.0010	FRONT SOCKET PLATE
8	041.0004.0500	HALL SENSOR
9	044.0004.0012	OUTPUT INDUCTANCE
10	021.0001.0279	SOCKET 500A
11	011.0013.0001	LOWER COVER
12	050.0002.0056	OUTPUT FILTER BOARD
13	011.0013.0002	INTERNAL PLATE
14	042.0003.0047	POWER TRANSFORMER
15	032.0002.2003	ISOTOP DIODE
16	015.0001.0012	HEAT SINK
17	050.0001.0081	SNUBBER BOARD
18	011.0001.0512	LATERAL RIGHT COVER
19	030.0017.2202	RESISTOR
20	032.0001.8216	THREE PHASE RECTIFIER
21	011.0013.0006	UPPER PLATE
22	011.0013.0005	CONVEYOR PLATE
23	011.0013.0007	INTERNAL FAN SUPPORT
24	003.0002.0010	FAN
25	011.0013.0004	FRONT/REAR PLATE
26	010.0006.0035	FRONT/REAR PLASTIC PANEL
27	040.0001.0016	THREE-POLE SWITCH
28	013.0000.7006	REAR PANEL
29	045.0000.0017	CABLE CLAMP
30	045.0002.0009	SUPPLY CABLE
31	040.0006.1880	FUSE HOLDER
32	016.0011.0004	FUSE HOLDER CAP
33	022.0002.0268	REMOTE CONTROL WIRING
34	050.0001.0057	POWER SUPPLY CONTROL BOARD
35	050.0001.0055	BUS BOARD
36	041.0006.0006	TOROIDAL TRANSFORMER
37	050.0002.0053	LINE FILTER BOARD
38	011.0000.0500	UPPER COVER
39	031.1005.0228	CAPACITOR
40	050.0001.0052	SUPPLIES BOARD
41	050.0001.0054	POWER BOARD
42	011.0009.0047	HANDLE SUPPORT PLATE
43	016.0002.0001	PIN
44	012.0000.0005	COVER FOR HANDLE SUPPORT PLATE
45	011.0013.0013	HANDLE
46	011.0001.0513	LATERAL LEFT COVER
47	022.0002.0156	REMOTE DEVICE CONNECTION WIRING
48	011.0013.0018	REAR SOCKET PLATE

For ordering spares please state: Model: UWI 500 TP Serial no:

Pos no:

Code:

16 COMPONENTS AND SPARES UWF-102




N°	CODE	DESCRIPTION
1	011.0006.0003	SLIDE CLOSURE
2	050.5324.2400	LOGIC FRONT PANEL WF102 AIR
3	014.0002.0005	KNOB WITH POINTER
4	014.0002.0009	KNOB WITH POINTER
5	021.0001.2014	STING
6	021.0001.2000	COUPLING EURO
7	021.0001.2004	PLASTIC HOUSING
8	021.0001.2027	CAPILLARY TUBE
9	021.0001.0279	FIXED SOCKET 500A 95mmq
10	002.0000.0268	SPOOL HOLDER CAP
11	046.0004.0013	PLASTIC SUPPORT
12	011.0014.0005	LOWER COVER
13	050.0001.0041	MOTOR BOARD
14	011.0014.0012	SLIDING KIT
15	011.0001.0632	DOOR
16	021.0001.0379	FIX PLUG 500A 95mmq
17	011.0002.0018	SOLENOID VALVE PLATE
18	022.0002.0155	REMOTE LOGIC CABLE
19	017.0001.5542	SOLENOID VALVE
20	011.0014.0016	FIXING CABLE BUNDLE PLATE
21	011.0014.0018	SUPPORT CABLE BUNDLE PLATE
22	011.0014.0007	LOGIC PROTECTION PLATE
23	011.0014.0002	POSTERIOR PLATE
24	011.0014.0006	SPOOL SUPPORT PLATE
25	011.0006.0054	SPOOL SUPPORT
26	012.0000.0003	LOWER SPOOL COVER
27	016.0008.0003	CYLINDRICAL PLUG
28	012.0000.0004	UPPER SPOOL COVER
29	011.0001.0652	UPPER COVER
30	011.0014.0013	INTERNAL PLATE
31	011.0014.0008	UPPER COVER SUPPORT PLATE
32	011.0006.0021	HANDLE
33	011.0006.0007	PLASTIC HINGE
34	002.0000.0012	WIRE FEED MOTOR
35	011.0014.0001	FRONT PLATE

For ordering spares please state:

Model: UWF 102
Serial no:
Pos no:
Code:

17 WIRING DIAGRAM UWF-102



15 SAFETY INSTRUCTIONS

Arc Welding Hazards

The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.

Only qualified persons should install, operate, maintain, and repair this unit. During operation, keep everybody, especially children, away.

ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

Do not touch live electrical parts. Wear dry, hole-free insulating gloves and body protection. Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground. Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling. Use AC output ONLY if required for the welding process. If AC output is required, use remote output control if present on unit.

Disconnect input power before installing or servicing this equipment. Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in the cord plug and that the plug is connected to a properly grounded receptacle outlet. When making input connections, attach proper grounding conductor first – double-check connections. Frequently inspect input power cord for damage or bare wiring –replace cord immediately if damaged – bare wiring can kill. Turn off all equipment when not in use.

Do not use worn, damaged, undersized, or poorly spliced cables. Do not drape cables over your body. If earth grounding of the work-piece is required, ground it directly with a separate cable. Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.

Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual. Wear a safety harness if working above floor level. Keep all panels and covers securely in place. Clamp work cable with good metal-to-metal contact to work-piece or worktable as near the weld as practical. Insulate work clamp when not connected to work-piece to prevent contact with any metal object. Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists after removal of input power on inverters. Turn off inverter, disconnect input power, and discharge input capacitors before touching any parts.

ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld. Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes when welding or watching. Wear approved safety glasses with side shields under your helmet. Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc. Wear protective clothing made from durable, flame-resistant material (leather and wool) and foot protection.

FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health. Keep your head out of the fumes. Do not breathe the fumes. If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases. If ventilation is poor, use an approved air-supplied respirator. Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers. Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe. Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases. Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.

WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding. Protect yourself and others from flying sparks and hot metal. Do not weld where flying sparks can strike flammable material. Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers. Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Watch for fire, and keep a fire extinguisher nearby. Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side. Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared. Connect work cable to the work as close to the welding area as practical to prevent welding current from travelling long, possibly unknown paths and causing electric shock and fire hazards. Do not use welder to thaw frozen pipes. Remove stick electrode from holder or cut off welding wire at contact tip when not in use. Wear oil-free protective garments such as leather gloves, heavy shirt, cuff-less trousers, high shoes, and a cap. Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.

FLYING METAL can injure eyes.

Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag. Wear approved safety glasses with side shields even under your welding helmet.

BUILDUP OF GAS can injure or kill.

Shut off shielding gas supply when not in use. Always ventilate confined spaces or use approved air-supplied respirator.

HOT PARTS can cause severe burns.

Do not touch hot parts bare handed. Allow cooling period before working on gun or torch.

MAGNETIC FIELDS can affect pacemakers.

Pacemaker wearers keep away. Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.

NOISE can damage hearing.

Noise from some processes or equipment can damage hearing. Wear approved ear protection if noise level is high.

CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully. Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs. Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping. Keep cylinders away from any welding or other electrical circuits. Never drape a welding torch over a gas cylinder. Never allow a welding electrode to touch any cylinder. Never weld on a pressurized cylinder – explosion will result. Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition. Turn face away from valve outlet when opening cylinder valve. Keep protective cap in place over valve except when cylinder is in use or connected for use. Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.

Additional precautions for installation, operation, and maintenance

Do not install or place unit on, over, or near combustible surfaces. Do not install unit near flammables. Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.

FALLING UNIT can cause injury.

Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories. Use equipment of adequate capacity to lift and support unit. If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.

OVERUSE can cause OVERHEATING

Allow cooling period; follow rated duty cycle. Reduce current or reduce duty cycle before starting to weld again. Do not block or filter airflow to unit.

STATIC (ESD) can damage PC boards.

Put on grounded wrist strap BEFORE handling boards or parts. Use proper static-proof bags and boxes to store, move, or ship PC boards.

MOVING PARTS can cause injury.

Keep away from moving parts. Keep away from pinch points such as drive rolls.

WELDING WIRE can cause injury.

Do not press gun trigger until instructed to do so. Do not point gun toward any part of the body, other people, or any metal when threading welding wire.

ARC WELDING can cause interference.

Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.

Be sure all equipment in the welding area is electromagnetically compatible.

To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.

Locate welding operation 100 meters from any sensitive electronic equipment.

Be sure this welding machine is installed and grounded according to this manual.

If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

EMF Information

Considerations about welding and the effects of low frequency electric and magnetic fields.

Welding current, as it flows through welding cables, will cause electromagnetic fields.

There has been and still is some concern about such fields.

However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard."



However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:



1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Pacemakers:

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.

DECLARATION OF CONFORMITY		
We hereby state that the machine type:		UWI-500TP
		s.n. :
is in compliance with the directives:		2004/108/CE 2006/95/CE 2011/65/EU
and that the following standards apply:		EN 60974-1 EN 60974-10
Last two digits of the year CE marking:		14
<p style="text-align: right;">Belvedere, 01/01/2013</p> <p style="text-align: right;">Amm. Giorgio Toniolo</p> <p style="text-align: right;"></p> <p>WECO srl Via S. Antonio, 22 - BELVEDERE 36050 TEZZE SUL BRENTA (VICENZA) ITALY Tel. +39 0424 561943 - Fax +39 0424 561944 E-mail info@weco.it - www.weco.it P. IVA 02783960244 - C.F. 02710490281 Reg. Impr. VI n° 52214 - R.E.A. N° 274736 Capitale sociale i.v. € 52.000,00</p>		

ANY TAMPERING OR CHANGE UNAUTHORIZED BY WECO s.r.l. SHALL IMMEDIATELY INVALIDATE THIS STATEMENT.

DECLARATION OF CONFORMITY		
We hereby state that the machine type:		UWF-102
		s.n. :
is in compliance with the directives:		2004/108/CE 2006/95/CE 2011/65/EU
and that the following standards apply:		EN 60974-5 EN 60974-10
Last two digits of the year CE marking:		14
<p style="text-align: right;">Belvedere, 01/01/2013</p> <p style="text-align: right;">Amm. Giorgio Toniolo</p> <p style="text-align: right;"></p> <p>WECO srl Via S. Antonio, 22 - BELVEDERE 36050 TEZZE SUL BRENTA (VICENZA) ITALY Tel. +39 0424 561943 - Fax +39 0424 561944 E-mail info@weco.it - www.weco.it P. IVA 02783960244 - C.F. 02710490281 Reg. Impr. VI n° 52214 - R.E.A. N° 274736 Capitale sociale i.v. € 52.000,00</p>		

ANY TAMPERING OR CHANGE UNAUTHORIZED BY WECO s.r.l. SHALL IMMEDIATELY INVALIDATE THIS STATEMENT.

19 NOTES

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

FOR FULL INFORMATION ON THE UNITOR WELDING OFFER 

USE THE UNITOR WELDING HANDBOOK FOR MARITIME WELDERS



You can download it here

<http://www.wilhelmsen.com/services/maritime/companies/buss/DocLit/ProductLiterature/Pages/Maintenanceandrepair.aspx>

...or contact Wilhelmsen Ships Service for a paper copy

We service your needs in 2 200 ports...