

FN1650.2

| ITEM | ITW-Eurocode | DESCRIPTION |
|------|---------------|--------------------------------|
| | 576910 | FN1650.2 Sequential |
| 1 | 617539 | Screw |
| 2 | 617558 | Bushing |
| 3 | 617504 | Exhaust Cover |
| 4 | 576913 | Spring |
| 5 | 617533 | Screw |
| 6 | 617535 | Washer |
| 7 | 617489 | Cylinder Cap |
| 8 | 617550 | Gasket |
| 9 | 617548 | Seal |
| 10 | 617519 | Spring |
| 11 | 617521 | O-Ring |
| 12 | 617510 | Valve |
| 13 | 617527 | O-Ring |
| 14 | 617507 | Piston Stop |
| 15 | 617552 | Restrict Washer |
| 16 | 617551 | Cylinder Seal |
| 17 | 617523 | O-Ring |
| 18 | 576942 | Piston Unit |
| 19 | 617505 | Cylinder |
| 20 | 617524 | O-Ring |
| 21 | 617525 | O-Ring |
| 22 | 617503 | Collar |
| 23 | 617522 | O-Ring |
| 24 | 617506 | Bumper |
| 25 | 617508 | Joint Guide |
| 26 | 617526 | O-Ring |
| 27 | 617545 | Logo-1 |
| 28 | 617488 | Body |
| 29 | 576915 | Trigger Valve Unit |
| 30 | 576916 | Spring |
| 31 | 576959 | Trigger Contact Kit |
| 31 | 576918 | Trigger Sequential |
| 32 | 617537 | Spring Pin |
| 33 | 617553 | Safety Bracket |
| 34 | 576919 | Spring |
| 40 | 576920 | Safety Lever Unit |
| 41 | 617544 | Logo-2 |
| 42 | 617549 | Gasket |
| 43 | 617529 | Pin |
| 44 | 576943 | Driver Guide |
| 45 | 617531 | Screw |
| 46 | 576922 | Screw |
| 47 | 576923 | Plate |
| 48 | 576966 | Spring Washer |
| 49 | 576924 | Screw |
| 50 | 617547 | Washer |
| 51 | 576925 | Front Plate |
| 52 | 617530 | Pin |
| 53 | 576926 | Lock Lever Unit |
| 54 | 576927 | Pin |
| 55 | 576928 | Work Piece Contact A |
| 56 | 576944 | Pusher |
| 57 | 617520 | Guide |
| 58 | 576967 | Spring |
| 60 | 617538 | Screw |
| 61 | 617511 | Rear Plate |
| 62 | 617536 | Nut |
| 63 | 617556 | Cover |
| 64 | 617512 | Cover |
| 65 | 576945 | Movable Magazine Unit |
| 66 | 617496 | Rail |
| 67 | 576946 | Type Label Sequential |
| 67 | 576947 | Type Label Contact |
| 68 | 576948 | Fixed Magazine Unit Contact |
| 68 | 576949 | Fixed Magazine Unit Sequential |
| 69 | 576935 | Work Piece Contact B |
| 70 | 576936 | Support |
| 71 | 617540 | Screw |
| 72 | 617541 | Pin |
| 73 | 617555 | Lock |
| 74 | 576937 | Spring |
| 75 | 576938 | End Cap |
| 76 | 576939 | Belt Hook |
| 77 | 576940 | Screw |
| 78 | 617534 | Washer |
| 79 | 617509 | Air Plug |
| 80 | 576979 | Guide |
| | 576941 | Manual |

FN1850.2

| ITEM | ITW-Eurocode | DESCRIPTION |
|------|---------------|--------------------------------|
| | 576909 | FN1850.2 Sequential |
| 1 | 617539 | Screw |
| 2 | 617558 | Bushing |
| 3 | 617504 | Exhaust Cover |
| 4 | 576913 | Spring |
| 5 | 617533 | Screw |
| 6 | 617535 | Washer |
| 7 | 617489 | Cylinder Cap |
| 8 | 617550 | Gasket |
| 9 | 617548 | Seal |
| 10 | 617519 | Spring |
| 11 | 617521 | O-Ring |
| 12 | 617510 | Valve |
| 13 | 617527 | O-Ring |
| 14 | 617507 | Piston Stop |
| 15 | 617552 | Restrict Washer |
| 16 | 617551 | Cylinder Seal |
| 17 | 617523 | O-Ring |
| 18 | 576914 | Piston Unit |
| 19 | 617505 | Cylinder |
| 20 | 617524 | O-Ring |
| 21 | 617525 | O-Ring |
| 22 | 617503 | Collar |
| 23 | 617522 | O-Ring |
| 24 | 617506 | Bumper |
| 25 | 617508 | Joint Guide |
| 26 | 617526 | O-Ring |
| 27 | 617545 | Logo-1 |
| 28 | 617488 | Body |
| 29 | 576915 | Trigger Valve Unit |
| 30 | 576916 | Spring |
| 31 | 576917 | Trigger Contact Kit |
| 31 | 576918 | Trigger Sequential |
| 32 | 617537 | Spring Pin |
| 33 | 617553 | Safety Bracket |
| 34 | 576919 | Spring |
| 40 | 576920 | Safety Lever Unit |
| 41 | 617544 | Logo-2 |
| 42 | 617549 | Gasket |
| 43 | 617529 | Pin |
| 44 | 576921 | Driver Guide |
| 45 | 617531 | Screw |
| 46 | 576922 | Screw |
| 47 | 576923 | Plate |
| 48 | 576966 | Spring Washer |
| 49 | 576924 | Screw |
| 50 | 617547 | Washer |
| 51 | 576925 | Front Plate |
| 52 | 617530 | Pin |
| 53 | 576926 | Lock Lever Unit |
| 54 | 576927 | Pin |
| 55 | 576928 | Work Piece Contact A |
| 56 | 576929 | Pusher |
| 57 | 617520 | Guide |
| 58 | 576967 | Spring |
| 60 | 617538 | Screw |
| 61 | 617511 | Rear Plate |
| 62 | 617536 | Nut |
| 63 | 617556 | Cover |
| 64 | 617512 | Cover |
| 65 | 576930 | Movable Magazine Unit |
| 66 | 617496 | Rail |
| 67 | 576931 | Type Label Sequential |
| 67 | 576932 | Type Label Contact |
| 68 | 576933 | Fixed Magazine Unit Contact |
| 68 | 576934 | Fixed Magazine Unit Sequential |
| 69 | 576935 | Work Piece Contact B |
| 70 | 576936 | Support |
| 71 | 617540 | Screw |
| 72 | 617541 | Pin |
| 73 | 617555 | Lock |
| 74 | 576937 | Spring |
| 75 | 576938 | End Cap |
| 76 | 576939 | Belt Hook |
| 77 | 576940 | Screw |
| 78 | 617534 | Washer |
| 79 | 617509 | Air Plug |
| 80 | 576979 | Guide |
| | 576941 | Manual |



