





No.	Code	Name	No.	Code	Name
1	613327	CAP ASSEMBLY	40	613693	C - RING
2	573259	DEFLECTOR	41	613692	FEED PISTON CAP
3	501901	BOLT ASSY	42	613691	FEED BUMPER
4	613740	SEAL	43	613690	SPRING A COMPRESSSION
5	613741	COMPRESSION SPRING	44	613760	O - RING
6	613742	OIL SEAL	45	613759	FEED PISTON
7	613743	O - RING	46	613254	O - RING
8	613744	HD.VALVE PISTON	47	613703	DOOR LATCH
9	613745	O - RING	48	613702	LATCH SPRING
10	573267	PACKING	49	613236	SPRING PIN
11	613883	DRIVER ASSEMBLY	50	571584	E - RING
12	613746	PISTON RING	51	613769	PIN
13	613747	O - RING	52	613768	PIN-NAIL STOP
14	613752	CYLINDER PRESS RING	53	613766	FIRST STOPPER FINGER
15	613884	CYLINDER ASSEMBLY	54	613767	SECOND STOPPER FINGER
16	613750	O - RING	55	613765	STOPPER FINGER SPRING
17	613751	CYLINDER RING	56	613764	DOOR
18	573273	BUMPER	57	613710	BOLT CAP
19	613754	GUN BODY UNIT	58	613782	SAFETY COVER
20	574360	AIR PLUG	59	613727	FIXED PIN
21	571563	DUSTY COVER	60	613728	FIXED RING
22	613244	O - RING	61	613784	MUZZLE PROTECTOR
23	613681	END CAP	62	613783	STOPPER
24	613273	HEX.SOC.HD.BOLT	63	613757	SAFETY GUIDE
25	613724	FLAT WASHER	64	613781	SAFETY SPRING
26	---	LOGO LABEL	65	613780	SAFETY B
27	613237	SPRING PIN	66	613885	SAFETY ASSEMBLY
28	613758	O - RING	67	613776	PROTECTIVE CASING
29	613242	SPRING	68	613773	MAGAZINE COVER
30	613753	TRIGER UNIT (sequential)	69	613099	WARNING LABEL
30	574717	TRIGER UNIT (contact)	70	613718	SPRING BASE A
31	613736	TRIGGER VAVLE ASSEMBLY	71	613719	PULL SPRING
32	501940	BOLT ASSY	72	613772	SPACER
33	613886	NOSE ASSEMBLY	73	613775	LOCK NUT
34	613763	PIN FEED PISTON	74	613770	MAGAZINE CASE
35	613761	FEED FINGER	75	613774	MAGAZINE SHAFT PIN
36	613762	FEED FINGER SPRING	76	613771	SPRING BASE
37	613755	O - RING	77	505916	MODEL LABEL (sequential)
38	613253	PU RETAINER	77	505917	MODEL LABEL (contact)
39	613266	DOOR SHAFT PIN	78	505932	MANUAL