

Cow Hitch

Disconnection assisted by the use of a Pig tail.

1. Connect the main rope and mooring tail in a cow hitch.



2. Enter the pig tails the eyes as shown in picture below.



3. Tension the cow hitch and attach the loose ends to either side.



4. Disconnect the cow hitch by pulling to each side to open

