

# MEMBRA® Adhesive Primer

Primer for Membra® membrane system

## Description :

Adhesive primer for ensuring good and lasting adhesion to absorbent substrates, as well as priming of details in the Membra Wet Room System. The primer binds immediately and requires short drying time.



## Application :

Membra Adhesive Primer is part of the Membra Wet Room System. The primer is used to ensure good adhesion to concrete and other porous substrates, as well as to ensure good adhesion between the membrane fabric and the surfaces of the other components in the Membra membrane system.

## Storage :

Protect from sunlight. Do not expose to temperatures higher than 50 °C. Store the product separately from food and keep out of the reach of children

## Installation :

The surface must be clean and dry. Spray an even layer from a distance of about 20 cm from the surface. For highly absorbent surfaces, apply a second layer. Wear gloves, safety glasses and a dust mask when applying. Ensure good ventilation. See the installation instructions and safety data sheets.

For more details see laying instruction on our website.

## Accessories for :

MEMBRA® Membranduk

## Approvals and guarantee



# MEMBRA® Adhesive Primer 620800

Product data	Value	Designation
Volume	750	ml

