

Installation Manual

AIR-TO-WATER HEATPUMP OUTDOOR UNIT

WH-WDG05LE5, WH-WDG07LE5,
WH-WDG09LE5



CAUTION

R290

REFRIGERANT

This AIR-TO-WATER HEATPUMP contains
and operates with refrigerant R290.

**THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED
BY QUALIFIED PERSONNEL.**

**Refer to National, State, Territory and local legislation,
regulations, codes, installation & operation manuals, before
the installation, maintenance and/or service of this product.**

Required tools for Installation Works

1 Phillips screw driver	13 Multimeter
2 Level gauge	14 Torque wrench
3 Electric drill, hole core drill	18 N•m (1.8 kgf•m)
4 Hexagonal wrench	42 N•m (4.3 kgf•m)
(4 mm)	55 N•m (5.6 kgf•m)
5 Spanner	65 N•m (6.6 kgf•m)
6 Pipe cutter	100 N•m (10.2 kgf•m)
7 Reamer	15 Hand gloves
8 Knife	(for refrigerant circuit repair)
9 Gas leak detector	16 Vacuum pump
10 Measuring tape	17 Gauge manifold
11 Thermometer	18 Recovery machine
12 Megameter	19 Recovery cylinder)

Explanation of symbols displayed on the indoor unit or outdoor unit.



WARNING

This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire/explosion.



CAUTION

This symbol shows that the Installation Manual should be read carefully.



CAUTION

This symbol shows that a service personnel should be handling this equipment with reference to the Installation Manual.



CAUTION

This symbol shows that there is information included in the Operation Manual and/or Installation Manual.

SAFETY PRECAUTIONS

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- Electrical work and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring or negligence of the instruction will cause harm or damage, and the seriousness is classified by the following indications.
- Please leave the installation manual with the unit after installation.



WARNING

This indication shows the possibility of causing death or serious injury.



CAUTION

This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by the symbols:



Symbol with white background denotes item that is PROHIBITED.



Symbol with dark background denotes item that must be carried out.

- Carry out test running to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- This appliance is not intended for accessibility by the general public.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.



WARNING



Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.



Do not install outdoor unit near handrail of veranda. When installing outdoor unit at veranda of high rise building, child may climb up to outdoor unit and cross over the handrail and causing accident.



Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.



Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.

	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. 
	Do not sit or step on the unit, you may fall down accidentally. 
	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing.
	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc.. They might cause electrical shock or fire.
	Do not modify the wiring of outdoor unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.
	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat above 370°C, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.
	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.
	For electrical work, follow local wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.
	Engage dealer or specialist for installation. If installation done by the user is defective, it will cause water leakage, electrical shock or fire.
	- The refrigerant cycle is completed inside the outdoor unit. - Refrigerant piping work is not required. - Pump down operation is not also required.
	For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.
	Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
	Do not use joint cable for outdoor connection cable. Use specified outdoor connection cable, refer to instruction ④ CONNECT THE CABLE TO THE OUTDOOR UNIT and connect tightly for outdoor connection. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.
	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause fire or electrical shock.
	After completion of installation, confirm there is no leakage of refrigerant gas. It may lead to the risk of fire or explosion when the refrigerant contacts with fire.
	Ventilate the room if there is refrigerant gas leakage during operation. Extinguish all fire sources if present. It may lead to the risk of fire or explosion when the refrigerant contacts with fire.
	Only use the supplied or specified installation parts, else, it may cause unit vibrate loose, water leakage, electrical shock or fire.
	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.
	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.
	Any work carried out on the outdoor unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.
	Be aware that refrigerants may not contain an odour.
	This unit must be properly earthed. The electrical earth must not be connected to a gas pipe, water pipe, the earth of lightning rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the outdoor unit.
 CAUTION	
	Do not install the outdoor unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.
	Do not release refrigerant during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
	Make sure the insulation of power supply cord does not contact hot part (i.e. refrigerant piping) to prevent from insulation failure (melt).
	Do not touch the sharp aluminium fin, sharp parts may cause injury. 
	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this outdoor unit may increase the risk of rupture and this may result in loss damage or injury and/or property.
	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.
	Installation work. It may need two or more people to carry out the installation work. The weight of outdoor unit might cause injury if carried by one person.
	Keep any required ventilation openings clear of obstruction.
	Water piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service.
	Precautions shall be taken to avoid excessive vibration or pulsation to water piping.
	Protect the water piping from accidental rupture due to moving furniture or reconstruction activities.
	- Must ensure the installation of water pipe-work shall be kept to a minimum. Avoid use dented pipe and do not allow acute bending. - Must ensure that water pipe-work shall be protected from physical damage.

PRECAUTION FOR USING R290 REFRIGERANT

- pay careful attention to the following points:

WARNING

	The mixing of different refrigerants within a system is prohibited.
	Operation, maintenance, repairing and refrigerant recovery should be carried out by trained and certified personnel in the use of flammable refrigerants and as recommended by the manufacturer. Any personnel conducting an operation, servicing or maintenance on a system or associated parts of the equipment should be trained and certified.
	Any part of refrigerating circuit (evaporators, air coolers, AHU, condensers or liquid receivers) or piping should not be located in the proximity of heat sources, open flames, operating gas appliance or an operating electric heater.
	The user/owner or their authorized representative shall regularly check the alarms, mechanical ventilation and detectors, at least once a year, where as required by national regulations, to ensure their correct functioning.
	A logbook shall be maintained. The results of these checks shall be recorded in the logbook.
	In case of ventilations in occupied spaces shall be checked to confirm no obstruction.
	Before a new refrigerating system is put into service, the person responsible for placing the system in operation should ensure that trained and certified operating personnel are instructed on the basis of the instruction manual about the construction, supervision, operation and maintenance of the refrigerating system, as well as the safety measures to be observed, and the properties and handling of the refrigerant used.
	The general requirement of trained and certified personnel are indicated as below: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants; and, b) Detailed knowledge of and skills in handling flammable refrigerants, personal protective equipment, refrigerant leakage prevention, handling of cylinders, charging, leak detection, recovery and disposal; and, c) Able to understand and to apply in practice the requirements in the national legislation, regulations and Standards; and, d) Continuously undergo regular and further training to maintain this expertise.
	Ensure protection devices, refrigerating circuit and fittings are well protected against adverse environmental effects (such as the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris).

CAUTION

	1. Installation (Space) • Must comply with national gas regulations, state municipal rules and legislation. Notify relevant authorities in accordance with all applicable regulations. • Must ensure mechanical connections be accessible for maintenance purposes. • In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction. • When disposal of the product, do follow to the precautions in #12 and comply with national regulations. • Always contact to local municipal offices for proper handling.
	2. Servicing 2-1. Service personnel • Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification. • Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants. • Servicing shall be performed only as recommended by the manufacturer. • The system is inspected, regularly supervised and maintained by a trained and certified service personnel who is employed by the person user or party responsible. • Ensure refrigerant charge not to leak. 2-2. Work • Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised. • For repair to the refrigerating system, the precautions in #2-2 to #2-8 must be followed before conducting work on the system. • Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed. • All maintenance staff and others working in the local area shall be instructed and supervised on the nature of work being carried out. • Avoid working in confined spaces. Always ensure away from source, at least 2 meter of safety distance, or zoning of free space area of at least 2 meter in radius. • Wear appropriate protective equipment, including respiratory protection, as conditions warrant. • Keep all sources of ignition and hot metal surfaces away. 2-3. Checking for presence of refrigerant • The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres. • Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe. • In case of leakage/spillage happened, immediately ventilate area and stay upwind and away from spill/release. • In case of leakage/spillage happened, do notify persons down wind of the leaking/spill, isolate immediate hazard area and keep unauthorized personnel out.

2-4. Presence of fire extinguisher

- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand.
- Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

2-5. No ignition sources

- No person carrying out work in relation to a refrigerating system shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. He/She must not be smoking when carrying out such work.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.

2-6. Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

2-7. Checks to the refrigerating equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants.
 - The ventilation machinery and outlets are operating adequately and are not obstructed.
 - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
 - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
 - Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are properly protected against being so corroded.

2-8. Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- Initial safety checks shall include but not limit to:-
 - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
 - That there are no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - That there is continuity of earth bonding.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- The owner of the equipment must be informed or reported so all parties are advised thereafter.

3. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

4. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
- The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer. Unspecified parts by manufacturer may result ignition of refrigerant in the atmosphere from a leak.

5. Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

6. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

!	7. The following leak detection methods are deemed acceptable for all refrigerant systems. - No leaks shall be detected when using detection equipment with a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0.25 times the maximum allowable pressure (>0.98MPa, max 3.90MPa). For example, a universal sniffer. - Electronic leak detectors may be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) - Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. - Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed. - Leak detection fluids are also suitable for use with most refrigerants, for example, bubble method and fluorescent method agents. The use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. - If a leak is suspected, all ignition sources shall be removed/extinguished. - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system. The precautions in #8 must be followed to remove the refrigerant.
!	8. Removal and evacuation When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to: • remove refrigerant -> • purge the circuit with inert gas -> • evacuate -> • purge with inert gas -> • open the circuit by cutting. Brazing must not be used. - The refrigerant charge shall be recovered into the correct recovery cylinders. - The system shall be purged with OFN to render the appliances safe. (remark: OFN = oxygen free nitrogen, type of inert gas) - This process may need to be repeated several times. - Compressed air or oxygen shall not be used for this task. - Purging shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. - This process shall be repeated until no refrigerant is within the system. (Until the concentration of purge gas is 0.25 LFL or less by the leak detector), $\approx 0.25\text{LFL} = 0.525\text{Vol}\%$ - When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. - This operation is absolutely vital if brazing operations on the pipe work are to take place. - Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and there is ventilation available.
!	9. Charging procedures - In addition to conventional charging procedures, the following requirements shall be followed. - Ensure that contamination of different refrigerants does not occur when using charging equipment. - Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them. - Cylinders shall be kept in an appropriate position according to the instructions. - Ensure that the refrigerating system is earthed prior to charging the system with refrigerant. - Label the system when charging is complete (if not already). - Extreme care shall be taken not to over fill the refrigerating system. - Prior to recharging the system it shall be pressure tested with OFN (refer to #8). - The system shall be leak tested on completion of charging but prior to commissioning. - A follow up leak test shall be carried out prior to leaving the site. - Electrostatic charge may accumulate and create a hazardous condition when charging and discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.
!	10. Decommissioning - Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details. - It is recommended good practice that all refrigerants are recovered safely. - Re-use of recovered refrigerant is prohibited. - It is essential that electrical power is available before the task is commenced. - Become familiar with the equipment and its operation. - Isolate system electrically. - Before attempting the procedure ensure that: - mechanical handling equipment is available, if required, for handling refrigerant cylinders; - all personal protective equipment and leak detectors are available and being used correctly; - the recovery process is supervised at all times by a competent person; - recovery equipment and cylinders conform to the appropriate standards. - Make sure that cylinder is situated on the scales before recovery takes place. - Start the recovery machine and operate in accordance with instructions. - Do not over fill cylinders. (No more than 80 % volume liquid charge). - Do not exceed the maximum working pressure of the cylinder, even temporarily. - When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off. - Electrostatic charge may accumulate and create a hazardous condition when charging or discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.
!	11. Labelling - Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. - The label shall be dated and signed. - Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

12. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.
- Make sure the recovery equipment is not a potential ignition source and is suitable for the refrigerant you are using.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

Attached accessories

No.	Accessories part	Qty.
1	Drain elbow 	1
2	Rubber cap 	3
3	Discharge grille (left side) 	1
4	Discharge grille (right side) 	1
5	Screw 	4

Optional accessories

No.	Accessories part	Qty.
6	Base Pan Heater CZ-NE4P	1

- It is strongly recommended to install a Base Pan Heater (optional) if the outdoor unit is install in cold climate area. Refer the Base Pan Heater (optional) installation instruction for details of installation.

1 SELECT THE BEST LOCATION

- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- For WH-WDG05LE5, WDG07LE5 and WDG09LE5, avoid installations in areas where the ambient temperature may drop below -25°C.
- A protective zone is defined for the area close around the product. See section "2 Protective zone".
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If outdoor unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc), it lifespan maybe shorten.
- Please follow the table below for water piping specifications.

Model	Water piping between outdoor unit and indoor unit			
	Inner diameter	Maximum length	Insulator thickness	Maximum Elevation
WH-WDG05LE5	ø20	30 m	30 mm or more	10 m
WH-WDG07LE5	ø25			
WH-WDG09LE5				

2 PROTECTIVE ZONE

This outdoor unit is filled with R290(Extremely flammable gas, safety A3 group per ISO 817). Note that this refrigerant has a higher density than air. In case of a refrigerant leak, the leaked refrigerant may accumulate near the ground.

Prevent accumulation of refrigerant in any way that is potentially dangerous, explosive or risk suffocation. Prevent refrigerant from entering the building through building openings. Prevent accumulation of refrigerant in the drain grooves.


A protective zone is defined around this outdoor unit. There must be no building openings, windows, doors, light shafts, cellar entrances, escape hatches, flat-roof windows or ventilation openings in the protective zone.

There must be no ignition sources, such as heat above 360°C, sparks, open flame, plug sockets, light switches, lamps, electrical switches or other permanent ignitions sources, in the protective zone.

The protective zone must not extend to adjacent buildings or public traffic areas (boundaries of neighbors, the public road, neighbor's private roads, subsidence area, depressions, pump shafts, sewers intakes, waste water shafts and so on.).


In the protective zone, you are not permitted to make any subsequent structural alterations which infringe the stated rules for the protective zone.

- 1) Protective zone for ground installation (or flat-roof installation) at the open areas




A 1000 mm

- 2) Protective zone for ground installation in front of a building wall




A 2000 mm
B 3000 mm
C 300 mm
D 1000 mm

- 3) Protective zone for ground installation in a building corner



A 2000 mm
B 2500 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


- 4) Protective zone for wall installation in front of a building wall



A 2000 mm
B 3000 mm
C 300 mm
D 1000 mm

The protective zone under the product extends to the floor.

- 5) Protective zone for wall installation in a building corner




A 2000 mm
B 2500 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


The protective zone under the product extends to the floor.

3 INSTALL THE OUTDOOR UNIT


DIMENSION DIAGRAM




Top view




Front view



Side view




Rear view




Bottom view

	Size	Torque
Water inlet port	Rc 1"	88.2 N•m
Water outlet port		



- After selecting the best location, start installation according to Installation Diagram.
- When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.
- When installing to a concrete or solid surface, use M10 or a W 3/8 bolts and nuts to secure the unit. Ensure that it is installed upright on a horizontal plane. (Use an anchor bolt for the installation as shown in the diagram below.)



DISPOSAL OF OUTDOOR UNIT DRAIN WATER

- When a Drain elbow ① is used, please ensure to follow below:
 - the unit should be placed on a stand which is taller than 50 mm.
 - cover the ø32mm holes with Rubber cap ② (refer to illustration below).
 - use a tray (field supply) when necessary to dispose the outdoor unit drain water.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow ① and Rubber cap ②, for the drain water freezes and the fan will not rotate.

Pressure relief valve drainage pipe-work

- Use a drain hose with inner diameter of 15mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wavy pattern of drain hose.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.








Illustration of how to fix drain hose to unit

4 CONNECT THE CABLE TO THE OUTDOOR UNIT

(FOR DETAIL REFER TO WIRING DIAGRAM AT UNIT)

1. Attach the discharge grille (left side) ⑬ for safety before connecting the cable.



2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed flexible cable (see below table), type designation 60245 IEC 57 or heavier cable. Sheath diameter of connecting cable shall be within specification (see below table) to fit cable gland.

Flexible cable specification	Cable diameter
$4 \times \min 2.5\text{mm}^2$	$\phi 12.0\text{-}14.0$

3. Route the cable as follows

*1 Locally procured cabtyre cables with the specified diameter.

*2 Must be fastened with the specified torque Viewpoint of gas intrusion prevention.

- ① Remove the front plate (Fig. 4-1)
- ② Remove the terminal cover and cable gland cap (Fig. 4-2)
- ③ Insert the cabtyre cable *1 (Fig. 4-3, 4-4)
(Pulled in from the rear panel and inserted from the bottom of the electric controller BOX)
- ④ Connect to terminal block (Fig. 4-5)
- ⑤ Fasten the cable gland *2 (Fig. 4-4)
- ⑥ Set the terminal cover *2 (Fig. 4-2)
- ⑦ Set the front plate (Fig. 4-1)




Fig. 4 - 1




Fig. 4 - 2

The cabinet top plate does not need to be removed.





Fig. 4 - 3






Fig. 4 - 4



⚠ WARNING

This equipment must be properly earthed.

Terminals on the indoor unit	1	2	3	
Colour of wires				
Terminals on the outdoor unit	1	2	3	

Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157 ~ 196 {16 ~ 20}
M5	196 ~ 245 {20 ~ 25}

WIRE STRIPPING AND CONNECTING REQUIREMENT





Fig. 4 - 5

5 PIPE INSULATION

1. Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.

6 INSTALL THE DISCHARGE GRILLE

1. Remove the 3 screws fastened to the cabinet front plate. (Fig. 6-1)
2. Insert 4 claws of the discharge grille (right side) and fasten the 3 screws. (Fig. 6-2)

⚠ CAUTION

Make sure to install the discharge grille to the outdoor unit before powering ON to protect against a rotating fan.




Fig. 6-1




Fig. 6-2

⚠ CAUTION

If cleaning of the outdoor unit is necessary during installation or servicing, do not clean the outdoor unit with any hydrocarbon based solvent.

Installasjonshåndbok

LUFT-TIL-VANN VARMEPUMPE, UTENDØRSENHET

WH-WDG05LE5, WH-WDG07LE5,
WH-WDG09LE5



OBS

R290 KJØLEMIDDEL

Denne LUFT-TIL-VANN VARMEPUMPEN
inneholder og fungerer med kjølevæskan R290.

DETTE PRODUKTET SKAL BARE INSTALLERES ELLER VEDLIKEHOLDES
AV KVALIFISERT PERSONALE.

Se lovgivning, forskrifter, koder, installasjons- og brukerveiledninger for
nasjon, stat, område og lokalt, for installasjonen, vedlikeholdet og/eller
servicen for dette produktet.

Nødvendig verktøy for installasjonsarbeidet

1 Phillips skrutrekker	13 Multimeter
2 Nivåmåler	14 Skiftenøkkel
3 Elektrisk drill, hullkjernedril	18 N•m (1,8 kgf•m)
4 Heksagonal nøkkel	42 N•m (4,3 kgf•m)
(4 mm)	55 N•m (5,6 kgf•m)
5 Fastnøkkel	65 N•m (6,6 kgf•m)
6 Rørkutter	100 N•m (10,2 kgf•m)
7 Brotsj	15 Hansker
8 Kniv	(for reparasjon av kjølemiddelkrets)
9 Gasslekkasjedetektor	16 Vakuumpumpe
10 Målbånd	17 Manifoldmåler
11 Termometer	18 Gjenvinningsmaskin
12 Megameter	19 Gjenvinningsylinder)

Forklaring for symboler som vises på innendørsenheten eller utendørsenheten.

	ADVARSEL	Dette symbolet viser at dette utstyret bruker et brennbart kjølemiddel med sikkerhetsgruppe A3 i henhold til ISO 817. Hvis det lekker kjølemiddel sammen med en ekstern tennkilde, er det mulighet for brann/eksplosjon.
	OBS	Dette symbolet viser at installasjonshåndboken må leses nøye.
	OBS	Dette symbolet viser at vedlikeholdspersonalet skal håndtere dette utstyret med referanse til installasjonshåndboken.
	OBS	Dette symbolet viser at det finnes informasjon i Brukanvisningen og/eller Installasjonshåndboken.

SIKKERHETSTILTAK

- Les følgende "SIKKERHETSTILTAK" nøye før installasjonen.
- Elektrisk arbeid og arbeid med vanninstallasjoner må gjøres henholdsvis av autorisert elektroinstallatør og autorisert rørleggerfirma. Pass på å bruke rett type stikkontakt og strømkrets for modellen som skal installeres.
- Forsiktighetsreglene her må følges fordi disse inneholder viktige sikkerhetsregler. Betydningen av hver indikasjon som brukes oppgis nedenfor. Uriktig installasjon skyldes at instruksjonen ignoreres eller ikke følges, kan forårsake skade eller ødeleggelse, og alvorlighetsgraden klassifiseres etter følgende indikasjoner.
- Oppbevar installasjonshåndboken sammen med enheten etter installasjonen.

	ADVARSEL	Denne indikasjonen viser fare som kan føre til død eller alvorlig skade.
	OBS	Denne indikasjonen viser fare som kan føre til skade på person eller eiendom.

Punktene som må følges klassifiseres med symbolene:

	Symbol med hvit bakgrunn henviser til ting som FORBUDT.
	Symbol med mørk bakgrunn angir noe som må gjøres.

- Utfør en testkjøring for å være sikker på at det ikke inntreffer noe unormalt etter installasjonen. Forklar deretter brukeren om drift, stell og vedlikehold som oppgitt i instruksjonene. Minn kunden om at han må ta vare på driftsinstruksjonene slik at han kan slå opp senere.
- Dette apparatet er ikke beregnet for bruk av vanlige personer.
- Hvis du er i tvil om installasjonsprosedyren eller driften, skal du alltid ta kontakt med en autorisert forhandler for råd og informasjon.

ADVARSEL

	Ikke bruk hjelpemidler for å akselerere avisingsprosessen eller for å rengjøre, unntatt det som er anbefalt av produsenten. Bruk av uegnet metode eller bruk av inkompatibelt materiale kan føre til skade på produktet, sprekke og alvorlig personskade.
	Ikke monter utendørsenheten inntil balkongrekkverk. Når utendørsenheten monteres på balkong i blokk, kan barn klatre opp på utendørsenheten, noe som kan føre til ulykke dersom barnet kommer over rekkverket og faller ned.
	Ikke bruk uspesifiserte ledninger, modifiserte ledninger, koble ledninger eller forlengelsesledninger til strømkabelen. Ikke del kontakten med annet elektrisk utstyr. Dårlig kontakt, dårlig isolasjon eller overspenning vil forårsake elektrisk støt eller brann.
	Ikke bind strømkabelen sammen i en bunt med bånd. Uvanlig temperaturstigning på strømforsyningskabelen kan oppstå.

	For ikke fingrene eller andre gjenstander inn i enheten, en vifte som roterer med høy hastighet kan føre til skade. 
	Ikke sitt eller trakk på enheten, da du kan falle ned ved et uhell. 
	Oppbevar plastposer (emballeringsmaterie)l) utilgjengelig for små barn, da det kan klistre seg fast over nese og munn og forhindre pusting.
	Ikke kjøp uoriginale elektriske deler til installasjon, service, vedlikehold osv. Disse kan forårsake elektriske støt eller brann.
	Ikke endre kablingen på utendørs installasjon av andre komponenter (f.eks. varmer osv). Overbelastning av kabling eller tilkoblingspunkter for kabling kan føre til elektrisk støt eller brann.
	Ikke stikk eller brenn da utstyret er trykksatt. Ikke utsett utstyret for varme over 370 °C, flammer, gnister eller andre tennkilder. Ellers kan den eksplodere og forårsake skader eller død.
	Ikke fyll eller erstatt kjølemiddel med annet enn spesifisert type. Det kan medføre skade på produktet, sprekking og skade osv.
	Alt elektrisk arbeid må utføres etter de nasjonale lovene, standardene og reglene på stedet og i samsvar med denne installasjonsveiledningen. Det må brukes en uavhengig krets og enkeltuttak. Hvis kapasiteten for den elektriske kretsen ikke er tilstrekkelig eller hvis det er feil i elektrikerarbeidet, kan det forårsake elektrisk støt eller brann.
	Ta kontakt med forhandleren eller en spesialist ved installering. Hvis installering foretatt av brukeren er mangelfull, kan det føre til vannlekkasje, elektrisk støt eller brann.
	• Kjølemiddelkretsen er lukket innenfor utendørsenheten. • Det er ikke behov for røropplegg for kjølemidlet. • Det er heller ikke behov for nedpumpingsdrift.
	For arbeider på kjølemiddelsystemet må det installeres strengt i henhold til denne installasjonsveiledningen. Hvis installering er mangelfull, kan det føre til vannlekkasje, elektrisk støt eller brann.
	Installeres på et sterkt og solidt sted som kan stå imot enhetens vekt. Hvis stedet ikke er solid nok eller hvis installasjonen ikke er foretatt riktig, kan enheten falle ned og forårsake skade.
	Ikke bruk felles utendørs tilkoblingskabel. Bruk spesifisert utendørs tilkoblingskabel, se instruksjonen ④ TILKOBLING AV KABLEN TIL UTENDØRSSENHETEN og fest godt til utendørs-tilkoblingskabelen. Koble godt til og spenn fast kablen slik at eksterne krefter ikke påvirker klæmmene. Hvis tilkoblingen eller festet er feil, vil det føre til overoppheting eller brann i tilkoblingen.
	Ledningene må legges slik at dekeleiet på kontrolltavlen kan festes på riktig måte. Dersom dekeleiet til kontrolltavlen ikke festes ordentlig, kan det forårsake brann eller elektrisk støt.
	Når installasjonen er fullført, forsikre at det ikke er kjølegasslekkasje. Det kan medføre fare for brann eller eksplosjon dersom kjølemidlet kommer i kontakt med flammer.
	Ventiler rommet dersom det oppstår kjølegasslekkasje under drift. Utfør slukningsarbeid dersom det har oppstått brann. Det kan medføre fare for brann eller eksplosjon dersom kjølemidlet kommer i kontakt med flammer.
	Bruk bare leverte eller spesifiserte installasjonsdeler. Ellers kan det føre til at enheten vibrerer og kommer seg løs, vannlekkasje, elektrisk sjokk eller brann.
	Hvis du er i tvil om installasjonsprosedyren eller driften, skal du alltid ta kontakt med en autorisert forhandler for råd og informasjon.
	Når man installerer elektrisk utstyr i bygninger av metall- eller wirekledning, er det iht. til regelverket ikke tillatt med noen elektrisk kontakt mellom utstyr og bygningen. I dette tilfellet skal det installeres isolasjon mellom delene.
	Alt arbeid som utføres på utendørsenheten etter demontering av paneler som er festet med skruer, må utføres under oppsyn av autorisert forhandler og lisensiert montør.
	Vær oppmerksom på at kjølemidlet kanskje ikke inneholder lukter.
	Denne enheten må være ordentlig jordnet. Jordingen må ikke være koblet til gassrør, vannrør, jording for lynavledere eller telefoner. Dette kan føre til elektrisk støt dersom det oppstår isoleringsbrudd eller jordingsfeil på utendørsenheten.
 OBS	
	Ikke installer utendørsenheten på steder der det kan forekomme lekkasje av brennbare gasser. Hvis det lekker gass og den samler seg rundt enheten, kan det føre til brann.
	Ikke slipp ut kjølemiddel under reparasjon av kjølemiddeldeler. Vær forsiktig med det flytende kjølemiddelet, det kan forårsake frostskaer.
	Kontroller at isolasjonen på strømforsyningskabelen ikke berører varme deler (f.eks. kjølevæskerør) for å forhindre isolasjonsfeil (smelting).
	Rør ikke den skarpe aluminiumsfinnen. Skarpe deler kan forårsake skade. 
	Velg et installasjonssted som er lett tilgjengelig ved vedlikehold. Feil installasjon, vedlikehold eller reparasjon av denne utendørsenheten kan øke faren for brudd og dette kan medføre havariskader eller personskaer og/eller skade på eiendom.
	Forsikre deg om at polariteten er korrekt gjennom hele kablingen. Hvis ikke vil det forårsake elektriske støt eller brann.
	Installasjonsarbeid. Installasjonsarbeidet vil kanskje kreve to personer eller mer. Vekten til utendørsenheten kan forårsake personskaer dersom den bæres av én person.
	Oppbevar uønskede ventilasjonsåpninger uten hindring.
	Vannrør i området som brukes aktivt, skal monteres på en slik måte at de beskyttes mot utilsiktede skader ved drift og service.
	Det må tas forholdsregler for å unngå overdrevne vibrasjoner eller pulsering i vannrørene.
	Beskytt vannrørene mot utilsiktede brudd på grunn av møbler som flyttes eller oppussingsarbeider.
	• Må sørge for at installasjonen for vannrørsystemet holdes så liten som mulig. Unngå bruk av bøyde rør og ikke bruk skarpe bønder. • Må sørge for at installasjonen for vannrørsystemet beskyttes mot fysiske skader.

FORHOLDSREGLER FOR BRUK AV R290 KJØLEMIDDEL

- vær spesielt oppmerksom på følgende punkter:

⚠ ADVARSEL

❗	Det er forbudt å blande forskjellige kjølemidler i et system.
❗	Drift, vedlikehold, reparasjon og kjølemiddelutvinning skal utføres av trent og sertifisert personell ved bruk av brannfarlige kjølemidler og i henhold til de instruksjonene som mottas av produsenten. Ethvert personell som utfører drift, service eller vedlikehold på et system eller tilhørende utstyrsdeler skal trenes og sertifiseres.
❗	Enhver kjølekretsdel (fordamper, luftkjølere, luftbehandlingsenhet, kondensatorer eller væskemottakere) eller rørdninger bør ikke plasseres i nærheten av varmekilder, åpen flamme, drivgassapparat eller et elektrisk varmeapparat i drift.
❗	Brukeren/eieren eller deres autoriserte representant skal regelmessig sjekke alarmer, mekanisk ventilasjon og detektorer, minst en gang i året i henhold til nasjonale forskrifter, for å sikre at de fungerer korrekt.
❗	En loggbok skal opprettholdes. Resultatene bør registreres i loggboken.
❗	Ventilasjoner i okkuperte områder skal sjekkes for å bekrefte at det finnes ingen hindring.
❗	Før et nytt kjølesystem tas i bruk, skal personen som er ansvarlig for å sette systemet i drift sørge for at opplært og sertifisert driftspersonell instrueres i henhold til bruksanvisningen om konstruksjon, overvåkning, drift og vedlikehold av kjølesystemet, samt sikkerhetsforanstaltninger som skal iakttas, og egenskapene og håndteringen av kjølemediet som brukes.
❗	Det generelle kravet som gjelder utdannet og sertifisert personell angis som følger: a) Data om lovgivning, forskrifter og standarder for brannfarlige kjølemidler; og, b) Detaljert kjennskap til og ferdigheter i håndtering av brannfarlige kjølemidler, personlig verneutstyr, forebygging av kjølemiddellekkasje, håndtering av sylindere, lading, lekkasjedeteksjon, gjenvinning og bortskaffelse; og, c) Kunne forstå og sette i praksis kravene i nasjonal lovgivning, forskrifter og standarder og, d) Gjennomgå vanlig og videreutdanning for å opprettholde denne kompetansen på en kontinuerlig måte.
❗	Sørg for at beskyttelsesenheter, kjølemiddelkrets og tilkoblinger er godt beskyttet mot skadelige miljøpåvirkninger (som fare for vannoppsamling og frost i avlastningsrør eller oppsamling av smuss og partikler).

⚠ OBS

❗	1. Installasjon (Plass) - Må samsvare med nasjonale gassforskrifter, statlige regler og lovgivning. Gi beskjed til aktuelle myndigheter i samsvar med gjeldende forskrifter. - Må sikre at mekaniske forbindelser er tilgjengelige for vedlikeholdsformål. - I tilfeller som krever mekanisk ventilasjon må ventilasjonsåpningene holdes frie for hindringer. - Ved kassasjon av produktet må forholdsreglene i pkt. 12 følges og nasjonale forskrifter overholdes. - Ta alltid kontakt med lokale myndigheter for korrekt håndtering.
❗	2. Vedlikehold 2-1. Vedlikeholdspersonale - Alt kvalifisert personale som er involvert i arbeid med eller ved inngrep i kjølemiddelkretsen, skal inneha et gyldig sertifikat fra en akkreditert myndighet for industriell vurdering, som autoriserer kompetansen til å håndtere kjølemidler på sikker måte i samsvar med spesifikasjon for industrirelatert vurdering. - Vedlikehold skal bare gjennomføres slik som anbefalt av utstyrsprodusenten. Vedlikehold og reparasjon som krever assistanse av annet faglært personale, skal utføres under overvåking av den kompetente personen for bruk av brennbare kjølemidler. - Vedlikehold skal bare gjennomføres slik som anbefalt av produsenten. - Systemet skal inspiseres, overvåkes og vedlikeholdes av utdannet og sertifisert tjenestepersonell som er ansatt av personbrukeren eller parten som er ansvarlig. - Sørg for at kjølemiddelladningen ikke lekker. 2-2. Arbeid - Før arbeidet påbegynnes på systemer som inneholder brennbare kjølemidler, er det nødvendig med sikkerhetskontroller for å sikre at faren for antenning reduseres så langt mulig. - Ved reparasjon av kjølemiddelssystemet må forholdsreglene i pkt. 2-2 til 2-8 følges før det utføres arbeid på systemet. - Arbeid skal gjennomføres i henhold til en kontrollert prosedyre for å redusere faren for at det finnes brennbare gasser eller damp mens arbeidet utføres. - Alt vedlikeholdspersonale og andre som arbeider i nærområdet, skal instrueres og opplæres i typen arbeid som gjennomføres. - Unngå arbeid i lukkede rom. Sørg alltid for at du er borte fra kilden, minst 2 meter sikkerhetsavstand, eller regulering av ledig plassareal på minst 2 meter i radius. - Bruk passende verneutstyr, inkludert pustefilter, som forebyggende tiltak. - Hold alle tennkilder og varme metallflater borte. 2-3. Kontroll om det finnes kjølemiddel - Området skal kontrolleres med en passende kjølemiddeldetektor før og under arbeidet, for å sikre at teknikerne er klar over mulige brennbare atmosfærer. - Sørg for at lekkasjedeteksjonsutstyret som brukes, er passende for bruk med brennbare kjølemidler, dvs. uten gnister, med adekvat forseingling eller generelt sikret. - Ved lekkasje/søl må området umiddelbart ventileres og fortsette å være luftet og fri for søl/utslipp. - Ved lekkasje/søl må personer varsles dersom de befinner seg i medvind fra lekkasjen/sølet, fareområdet må umiddelbart isoleres og uautorisert personale må holdes borte.

2-4. Brannslukker tilstede

- Hvis det utføres noen varmearbeider på kjøleutstyret eller på tilknyttede deler, må det finnes passende brannslukningsutstyr lett tilgjengelig.
- Pass på at det finnes en pulver- eller CO₂-brannslukker i nærheten av ladeområdet.

2-5. Ingen tennkilder

- Ingen personer som utfører arbeid i forbindelse med et kjølesystem, skal bruke tennkilder på en slik måte at det kan medføre fare for brann eller eksplosjon. Han/hun må ikke røke når slikt arbeid utføres.
- Alle mulige tennkilder, inkludert røyking av sigaretter, skal holdes på tilstrekkelig avstand fra stedet for installasjon, reparasjon, fjerning og kassasjon, hvor det eventuelt kan slippes brennbart kjølemiddel ut i nærområdet.
- For arbeidet utføres skal området rundt utstyret kontrolleres for å sørge for at det ikke foreligger noen brennbare farer eller fare for antenning.
- Det skal settes opp skilt med "Røyking forbudt".

2-6. Ventilert område

- Sørg for at området er i friluft eller at det er passende ventilert for det gripes inn i systemet eller før det utføres varme arbeider.
- En viss grad av ventilasjon skal fortsette under hele perioden der det utføres arbeid.
- Ventilasjonen skal spre frigjort kjølemiddel på sikker måte og fortrinnsvis blåse det ut eksternt i luften.

2-7. Kontroller av kjøleutstyret

- Hvis det gjøres endringer på elektriske komponenter, skal disse være passende for formålet og med korrekte spesifikasjoner.
- Produsentens vedlikeholds- og serviceeringslinjer skal alltid overholdes.
- Ta kontakt med produsentens tekniske avdeling for assistanse i tvilstilfeller.
- De følgende kontroller skal utføres ved installasjoner som bruker brennbare kjølemidler.
 - Ventilasjonsutstyret og uttak betjenes på korrekt måte og blir ikke hindret.
 - Hvis det benyttes en indirekte kjølemiddelkrets, skal det kontrolleres at den sekundære kretsen inneholder kjølemiddel.
 - Merking på utstyret fortsetter å være synlig og lesbar. Merkingen og skilt som er uleselige, skal korrigeres.
 - Kjølerør eller komponenter er montert i en posisjon hvor det ikke er sannsynlig at de blir utsatt for stoffer som kan korrodere komponenter som inneholder kjølemiddel, med mindre komponentene er laget av materialer som er motstandsdyktige mot korrosjon eller er korrekt beskyttet mot korrosjon.

2-8. Kontroller av elektriske enheter

- Reparasjon og vedlikehold av elektriske komponenter skal inkludere innledende sikkerhetskontroller og prosedyrer for inspeksjon av komponenter.
- Innledende sikkerhetskontroller skal inkludere, men er ikke begrenset til:
 - At kondensatorer er utladet: Dette skal utføres på en sikker måte for å unngå mulighet for gnister.
 - At det ikke finnes strømførende komponenter og ledninger som er åpne under lading, gjenvinning eller tømming av systemet.
 - At jordforbindelser er korrekt tilkoblet.
- Produsentens vedlikeholds- og serviceeringslinjer skal alltid overholdes.
- Ta kontakt med produsentens tekniske avdeling for assistanse i tvilstilfeller.
- Hvis det eksisterer en feil som kan sette sikkerheten i fare, skal det ikke kobles noen elektrisk strømforsyning til kretsen før dette er tilfredsstillende behandlet.
- Hvis feilen ikke kan korrigeres umiddelbart, men det er nødvendig å fortsette operasjonen, skal det brukes en adekvat, midlertidig løsning.
- Eieren av utstyret må informeres eller det må rapporteres slik at alle parter er varslet i forhold til dette.

3. Reparasjoner på forseglede komponenter

- Under reparasjoner på forseglede komponenter skal alle elektriske strømforsyninger frakobles fra utstyret som det utføres arbeid på, for fjerning av forseglingsdeksler osv.
- Hvis det er absolutt nødvendig å ha en elektrisk tilførsel tilkoblet til utstyret under vedlikehold, skal det plasseres permanent lekkasjedeteksjonsutstyr på det mest kritiske stedet for å varsle om mulige farlige situasjoner.
- Det må utvises spesiell oppmerksomhet til følgende for å sikre at huset ikke endres på en slik måte at beskyttelsesnivået påvirkes ved arbeid på elektriske komponenter. Dette inkluderer skade på kabler, for mange tilkoblinger, terminaler som ikke er i henhold til originalspesifikasjonen, skade på tetninger, feil tilpasning av skjerm osv.
- Sørg for at apparatet er sikkert montert.
- Sørg for at tetninger eller tetningsmaterialer ikke er forringet slik at de ikke lenger er formålstjenlige for hindring av inntrengning av brennbar atmosfære.
- Utskiftingsdeler skal være i samsvar med produsentens spesifikasjoner.

MERK: Bruk av silikontetningsmiddel kan hindre effektiviteten for noen typer av lekkasjedeteksjonsutstyr. Egenskilde komponenter behøver ikke isoleres for det utføres arbeid på dem.

4. Reparasjoner på egenskilde komponenter

- Ikke tilfør noen permanent induktiv eller kapasitiv last til kretsen uten å sørge for at dette ikke overskrider den tillatte spenningen og tillatt strøm for utstyret som brukes.
- Egenskilde komponenter er de eneste typene som kan behandles mens de er aktive, i nærheten av brennbare atmosfærer.
- Testapparatet skal ha korrekt klassifisering.
- Erstatt bare komponenter med deler som er spesifisert av produsenten. Deler som ikke er spesifisert av produsenten, kan medføre antennelese av kjølemidlet i atmosfæren fra en lekkasje.

5. Kabling

- Kontroller at kablingen ikke blir utsatt for slitasje, korrosjon, for høyt trykk, vibrasjon, skarpe kanter eller noen andre negative miljøeffekter.
- Kontrollen skal også ta hensyn til aldringseffekter eller kontinuerlig vibrasjon fra kilder som kompressorer eller vifter.


6. Deteksjon av brennbare kjølemidler

- Mulige antenningskilder skal ikke i noe tilfelle brukes ved søking eller deteksjon av kjølemiddelekkasjer.
- Halogenbrennere (eller noen annen detektor som bruker bare flammer) skal aldri brukes.

!	7. Følgende metoder for lekkasjedeteksjon anses å gjelde for alle kjølemediesystemer. • Det skal ikke registreres noen lekkasjer ved bruk av registreringsutstyr med en følsomhet på 5 gram kjølemiddel per år eller bedre under trykk på minst 0,25 ganger maksimalt tillatt trykk (>0,98 MPa, maks. 3,90 MPa). For eksempel en universell sniffer. • Elektroniske lekkasjedetektorer kan brukes til å oppdage brannfarlige kjølemidler, men følsomheten kan ikke være tilstrekkelig, eller trenger omkalibrering. (Deteksjonsutstyr skal kalibreres på et kjølemidelfritt område.) • Sorg for at detektoren ikke er en mulig antenningsskilde og passer for kjølemidlet som brukes. • Lekkasjedeteksjonsutstyret skal innstilles på en prosentandel av LFL i kjølemidlet og skal kalibreres til kjølemidlet som brukes og den aktuelle prosentandelen av gass (maksimalt 25 %) bekrefte. • Lekkasjedeteksjonsvesker passer også for bruk med de fleste kjølemidler, for eksempel boblemetode og metode med fluoriserende midler. Bruk av rensmidler som inneholder klor, skal unngås da klor kan reagere med kjølemidlet og korrodere rørsystem av kobber. • Hvis det mistenkes lekkasjer, skal alle tennkilder fjernes/slukkes. • Hvis det registreres en lekkasje av kjølemedium som krever lodding, skal all kjølemiddel tappes fra systemet. Forholdsreglene i nr. 8 må følges når kjølemidlet fjernes.
!	8. Fjerning og evakuering • Ved inngrep i kjølemiddelkretsen for å utføre reparasjoner - eller av andre årsaker - skal det brukes konvensjonelle metoder. Men det er viktig at den beste metoden følges da det må tas hensyn til brennbarheten. Den følgende prosedyren skal overholdes: • fjern kjølemiddel -> • skyll kretsen med edelgass -> • evakuer -> • skyll med edelgass -> • åpne kretsen ved å skjære. Lodding må ikke brukes. • Kjølemiddelladingen skal gjenvinnes i korrekte gjenvinningssylindere. • Systemet skal skylls med OFN for å beholde utstyret trygt. (merk: OFN = oksygenfritt nitrogen, type inertgass) • Denne prosessen må kanskje gjentas flere ganger. • Kompressluft eller oksygen må ikke benyttes for denne oppgaven. • Skylling oppnås ved fylle vakuemet i systemet med OFN og fortsette å fylle til arbeidstrykket er nådd, deretter ventileres med luft og til slutt gjennopprettes vakuemet. • Denne prosessen skal gjentas inntil det ikke er noe kjølemiddel i systemet. (Inntil konsentrasjonen av tømt gass er 0,25 LFL eller mindre i en lekkasjedetektor.) $\times 0,25 \text{ LFL} = 0,525 \text{ Vol\%}$ • Når den endelige OFN-ladingen benyttes, skal systemet ventileres ned til atmosfæretrykk for at arbeidet skal kunne gjennomføres. • Operasjonen er svært viktig hvis det skal gjennomføres lodding av rørene. • Sorg for at uttaket for vakuumpumpen ikke er i nærheten av noen mulige tennkilder og at det finnes tilgjengelig ventilasjon.
!	9. Ladeprosedyrer • I tillegg til vanlige ladeprosedyrer skal følgende krav overholdes. - Sorg for at det ikke oppstår forurensinger i forskjellige kjølemidler ved bruk av ladeutstyret. - Slangor og rør skal være så korte som mulig for å redusere mengden av kjølemiddel i rørene. - Sylindere skal holdes i korrekt posisjon i samsvar med instruksjonene. - Sorg for at kjølesystemet er jordat før systemet lades med kjølemiddel. - Merk systemet når ladingen er ferdig (hvis ikke allerede merket). - Det må utvises ekstrem forsiktighet ved påfyllingen slik at kjølesystemet ikke overfylles. • Før ny lading av systemet skal det trykktestes med OFN (se pkt. 8). • Systemet skal lekkasjetestes etter ladingen, men før utlevering. • En ny lekkasjetest skal utføres før stedet forlates. • Det kan oppstå elektrostatisk lading ved lading og tømning av kjølemiddel, og dette kan medføre farlige situasjoner. For å unngå brann eller eksplosjoner må statisk elektrisitet spres under overføringen ved å jorde og koble sammen beholdere og utstyr før lading/tømning.
!	10. Driftsutkobling • Før denne prosedyren gjennomføres er det viktig at teknikeren er hel fortrolig med utstyret og alle deler. • Det anbefales som god praksis at alle kjølemidler gjenvinnes på trygg måte. • Gjenbruk av tappet kjølemiddel er forbudt. • Det er viktig at det finnes tilgjengelig elektrisk strøm før oppgaven påbegynnes. a) Gjør deg kjent med utstyret og funksjonen. b) Isoler systemet elektrisk. c) For prosedyren påbegynnes må det påses at: • mekanisk håndteringsutstyr er tilgjengelig - hvis påkrevet - for håndtering av kjølemiddelsylindere; • alt personlig verneutstyr og lekkasjedetektorer er tilgjengelig og blir brukt på korrekt måte; • gjenvinningsprosessen overvåkes til enhver tid av en kompetent person; • gjenvinningsutstyret og sylindrene er i samsvar med gjeldende standarder. d) Sorg for at sylindrene er plassert på vekten før gjenvinningen påbegynnes. e) Start gjenvinningsmaskinen og kjør den i samsvar med instruksjoner. f) Sylindrene må ikke overfylles. (Ikke mer enn 80 %-volum væskelading). g) Det maksimale arbeidstrykket i sylindrene må ikke overskrides, heller ikke midlertidig. h) Når sylindrene er korrekt fylt og prosessen er fullført, må det påses at sylindrene og utstyret fjernes fra stedet umiddelbart og at alle isolasjonsventiler i utstyret er stengt. • Det kan oppstå elektrostatisk lading ved lading eller tømning av kjølemiddel, og dette kan medføre farlige situasjoner. For å unngå brann eller eksplosjoner må statisk elektrisitet spres under overføringen ved å jorde og koble sammen beholdere og utstyr før lading/tømning.
!	11. Merking • Utstyret skal merkes med opplysning om at det er tatt ut av drift og at kjølemidlet er fjernet. • Merkingen skal være datert og signert. • Sorg for at det finnes etiketter på utstyret med opplysning om at utstyret inneholder brennbart kjølemiddel.

- 12. Gjenvinning**
- Ved fjerning av kjølemidlet fra et system, enten for vedlikehold eller for driftsutkobling anbefales det som god praksis at alle kjølemidler fjernes på trygg måte.
 - Ved overføring av kjølemiddel til sylindere må det påses at det bare benyttes egnede gjenvinningssylindere.
 - Sørg for at det er tilgjengelig et tilstrekkelig antall sylindere for å kunne tappe hele ladingen i systemet.
 - Alle sylindere som brukes, er beregnet for gjenvunnet kjølemiddel og merket for det aktuelle kjølemidlet (dvs. spesialsylindere for gjenvinning av kjølemidler).
 - Sylindere skal være fullstendige med trykkavlastningsventiler og tilhørende utkoblingsventiler i god stand.
 - Gjenvinningssylindere er evakuert og - hvis mulig - avkjølt før gjenvinningen påbegynnes.
 - Gjenvinningsutstyret skal være i god stand med tilgjengelige instruksjoner for utstyret og skal være passende for gjenvinning av brennbare kjølemidler.
 - Sørg for at gjenvinningsutstyret ikke er en mulig tenneklode og passer for kjølemidlet du bruker.
 - I tillegg skal det finnes et sett med kalibrerte vektskåler i god stand.
 - Slinger skal være fullstendige med lekkasjefrie frakoblingskoblinger og i god stand.
 - Før bruk av gjenvinningsmaskinen må det kontrolleres at den er i tilfredsstillende stand, er korrekt vedlikeholdt og at alle tilknyttede elektriske komponenter er forseglet for å hindre antenning ved eventuell frigjøring av kjølemiddel.
 - Ta kontakt med produsenten i tvilstilfeller.
 - Det gjenvunne kjølemiddel skal returneres til kjølemiddel-leverandøren i den korrekte gjenvinningssylinderen, og den aktuelle etiketten (Waste Transfer Note) skal være plassert.
 - Kjølemidler må ikke blandes i gjenvinningsenheter og spesielt ikke i sylindere.
 - Dersom kompressorer eller kompressoroljer skal fjernes, må det påses at de er evakuert til et akseptabelt nivå for å sikre at det ikke finnes brennbart kjølemiddel igjen i smøremidlet.
 - Evakueringsprosessen skal gjennomføres for kompressoren returneres til leverandøren.
 - Det skal bare tilføres elektrisk varme til kompressorhuset for å akselerere prosessen.
 - Når det tappes olje fra et system, skal det utføres på sikker måte.

Vedlagt tilbehør

Nr.	Tilbehørsdel	Ant.
1	Dreneringsalbue 	1
2	Gummiheite 	3
3	Utslippsgrill (venstre side) 	1
4	Utslippsgrill (høyre side) 	1
5	Skrue 	4

Alternativt tilbehør

Nr.	Tilbehørsdel	Ant.
6	Underlagsvarmer CZ-NE4P	1

- Det anbefales på det sterkeste å installere en underlagsvarmer (ekstraustyr) hvis utendørsenheten installeres i område med kaldt klima. Se installasjonsinstruksjonen for underlagsvarmer (ekstraustyr) for informasjon om installasjon.

1 VELG BESTE PLASSERING

- Hvis det er monteret en markise e.l. over enheten for å forhindre direkte sol eller regn, må du passe på at varmestraling fra kondensatoren ikke forhindres.
- For WH-WDG05LE5, WDG07LE5 og WDG09LE5 må det ikke installeres på steder hvor omgivelsestemperaturen kan falle under -25 °C.
- Det er definert en beskyttelsessone for området i nærheten av produktet. Se avsnittet "2 Beskyttelsessone".
- Ikke plasser forhindringer som kan forårsake kortslutninger på grunn av luft som slippes ut.
- Hvis en utendørs enhet installeres i nærheten av sjøen, regioner med høyt svovel- eller oljeinnhold (f.eks. maskinolje o.l.), kan enhetens levetid forkortes.
- Følg tabellen nedenfor for spesifikasjoner av vannrørene.

Modell	Vannrør mellom utendørsenhet og innendørsenhet			
	Innvendig diameter	Maksimal lengde	Isolasjonstykkelse	Maksimal heving
WH-WDG05LE5	ø20	30 m	30 mm eller mer	10 m
WH-WDG07LE5	ø25			
WH-WDG09LE5				

2 BESKYTTELSESSONE

Denne utendørsenheten er fylt med R290 (ekstremt brennbar gass, sikkerhetsgruppe A3 i henhold til ISO 817). Merk at dette kjølemedlet har en høyere tetthet enn luft. Ved kjølemedlekkasje kan det lekkede kjølemedlet samle seg opp i nærheten av underlaget.

Unngå oppsamling av kjølemedlet på alle måter som muligens kan være farlige, eksplosive eller medføre fare for kvelning. Unngå at kjølemedlet kommer inn i bygninger gjennom åpninger i bygningene. Unngå oppsamling av kjølemedlet i tappesporene.


Det er definert en beskyttelsessone rundt utendørsenheten. Det må ikke være noen åpninger i bygninger, vinduer, dører, lyssjakter, kjellerinn-ganger, nødutganger, vinduer i flatt tak eller ventilasjonsåpninger i beskyttelsessonen.

Det må ikke være noen tennkilder, som f.eks. varme over 360 °C, gnister, åpen flamme, pluggkontakter, lysbrytere, lamper, elektriske brytere eller andre permanente tennkilder, i beskyttelsessonen.

Beskyttelsessonen må ikke strekke seg frem til bygninger i nærheten eller offentlige trafikkområder (nabogrenser, offentlig vei, naboers private veier, skråninger, fordypninger, pumpeaksler, kloakkutløp, spillvannssjakter og så videre).



I beskyttelsessonen er det forbudt å gjøre noen etterfølgende strukturendringer som overtrer angitte regler for beskyttelsessonen.

- 1) Beskyttelsessone for installasjon på bakken (eller installasjon på flatt tak) i åpne områder




A 1000 mm

- 2) Beskyttelsessone for installasjon på bakken foran en bygningsvegg




A 2000 mm
B 3000 mm
C 300 mm
D 1000 mm

- 3) Beskyttelsessone for installasjon på bakken i et bygningshjørne



A 2000 mm
B 2500 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


- 4) Beskyttelsessone for vegginstallasjon foran en bygningsvegg



A 2000 mm
B 3000 mm
C 300 mm
D 1000 mm

Beskyttelsessonen under produktet strekker seg ut over gulvet.

- 5) Beskyttelsessone for vegginstallasjon i et bygningshjørne




A 2000 mm
B 2500 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


Beskyttelsessonen under produktet strekker seg ut over gulvet.

3 INSTALLER UTENDØRSENHETEN


MÅLDIAGRAM




Sett fra toppen




Sett foran



Sett fra siden




Sett bakfra




Sett fra undersiden

	Størrelse	Dreiemoment
Vanninntaksåpning	Rc 1"	88,2 N•m
Vannutløpsåpning		




- Når du har valgt den beste plasseringen, starter du installasjonen i henhold til installasjonsskjemaet.
- 1. Hvis du installerer ved tak, må du ta hensyn til sterk vind og eventuelt jordskjelv. Fest installasjonen skikkelig med bolter eller spiker.
- 2. Ved installasjon på betong eller en fast flate, brukes M10 eller W 3/8 bolter og muttere for å feste enheten. Sørg for at den er installert oppreist på en horisontal flate. (Bruk en ankerbolt ved installasjonen som vist på tegningen nedenfor.)




AVLØPSVANN UTENDØRSENHET FOR DRENERING AV VANN

- Når det brukes en dreneringsalbue **1**, må det sikres at følgende overholdes:
 - enheten bør plasseres på et stativ som er høyere enn 50 mm.
 - ø32 mm hull må stenges med gummihette **2** (se tegningen nedenfor).
 - bruk et kar (feltforsyning) når det er nødvendig å tømme utendørsenhets avløpsvann.
- Hvis enheten brukes i et område hvor temperaturen kan falle til under 0 °C i 2 eller 3 dager på rad, anbefales det ikke å bruke dreneringsalbue **1** og gummihette **2**, da tappevannet vil fryse og viften ikke vil rotere.



Sikkerhetsventil for dreneringsrør

- Bruk avløpsslange med indre diameter på 15 mm.
- Slangen må installeres med kontinuerlig fall og ut mot frostfrie omgivelser.
- Hvis tømmeslangen er lang, brukes et metallstøttefeste langs veien for å fjerne bølgemønsteret i tømmeslangen.
- Det vil dryppe vann fra denne slangen, derfor må utløpet fra denne slangen installeres i et område der utløpet ikke vil bli blokkert.
- Ikke sett denne slangen i kloakkavløp eller dreneringsrør som kan produsere ammoniakkgass, svovelgass osv.
- Hvis det er nødvendig må du bruke en klemme til å stramme slangen fast på koblingen, slik at du hindrer lekkasje.






Illustrasjon av hvordan man fester tømmeslangen til enheten

4 TILKOBLING AV KABELN TIL UTENDØRSENHETEN

(FOR DETALJER, SE APPARATETS KOPLINGSSKJEMA)

1. Fest utslippsgrillen (venstre side) ³ av sikkerhetsårsaker for kabelen tilkobles.



2. Tilkoblingskabel mellom innendørs- og utendørsenhet må være en godkjent fleksibel kabel (se tabellen nedenfor), med polykloroprenbeskyttelse, typebetegnelse 60245 IEC 57, eller en tykkere kabel. Skjermdiameter på tilkoblingskabel skal være innenfor spesifikasjonen (se tabell nedenfor) for å passe til kabelgjennomføringen.

Spesifikasjon fleksibel kabel	Kabeldiameter
$4 \times \text{min } 2,5 \text{ mm}^2$	$\varnothing 12,0-14,0$

3. Før kabelen på følgende måte

*1 Lokalt anskaffede skjermkabler med spesifisert diameter.

*2 Må festes med spesifisert moment Visningspunkt for forhindring av gassinntrenging.

- ① Fjern frontplaten (Fig. 4-1)
- ② Fjern terminaldekselet og hetten på kabelgjennomføringen (Fig. 4-2)
- ③ Sett inn skjermkabelen *1 (Fig. 4-3, 4-4)
- (Trukket inn fra bakpanelet og satt inn fra bunnen av den elektriske kontrollboksen)
- ④ Koble til terminalblokken (Fig. 4-5)
- ⑤ Fest kabelgjennomføringen *2 (Fig. 4-4)
- ⑥ Plasser terminaldekselet *2 (Fig. 4-2)
- ⑦ Plasser frontplaten (Fig. 4-1)




Fig. 4 - 1




Fig. 4 - 2

Det er ikke nødvendig å fjerne kabinettets topplate.





Fig. 4 - 3






Fig. 4 - 4



⚠ ADVARSEL

⚡ Dette utstyret må være ordentlig jordnet.

Terminaler på innendørs enhet	1	2	3	⚡
Farger på ledninger				
Terminaler på utendørs enhet	1	2	3	⚡

Koblingsskrue	Tiltrekkingsmoment cN•m {kgf•cm}
M4	157 ~ 196 {16 ~ 20}
M5	196 ~ 245 {20 ~ 25}

KABELSTRIPPING OG TILKOBLINGSKRAV




Fig. 4 - 5

5 ISOLASJON AV RØR

1. Utfør isolering ved rørtilkoblingsdel som beskrevet i installasjonsdiagrammet for innendørs-/utendørsenhet. Dekk til den isolerte rørenden slik at det ikke kommer vann inn i røret.

6 MONTER UTSLIPPSGRILLEN

1. Fjern de 3 skruene som er festet til kabinettets frontplate. (Fig. 6-1)
2. Sett inn 4 klør i utslippsgrillen (høyre side) [4] og fest de 3 skruene. (Fig. 6-2)

⚠ OBS

Sørg for at utslippsgrillen installeres på utendørsenheten før strømmen slås PÅ for å beskytte mot en roterende vifte.




Fig. 6-1




Fig. 6-2

⚠ OBS

Hvis det er nødvendig å rengjøre utendørsenheten under installasjon eller service, må det ikke brukes noen hydrokarbonbaserte løsemidler ved rengjøring av utendørsenheten.